

The “InclusionZone” Class*

J. H. Gove

*USDA Forest Service, Northern Research Station, 271 Mast Road, Durham, NH 03824 USA
(603) 868-7667; e-mail: jgove@fs.fed.us*

Thursday 7th November, 2013 2:21pm

*R `sampSurf` package vignette series paper: <http://sampsurf.r-forge.r-project.org/>.

Contents

1	Introduction	2	11.4.2 Plotting the object	41
2	The “InclusionZone” Class	3	11.5 The “hybridDLPSIZ” class	41
2.1	Class slots	4	11.5.1 Object creation	41
3	The “downLogIZ” Class	5	11.5.2 Plotting the object	43
4	The “standUpIZ” Class	6	12 The “standingTreeIZ” Class	43
4.1	Object creation	6	13 The “circularPlotIZ” Class	44
4.2	Plotting the object	8	13.1 Object creation	44
5	The “chainSawIZ” Class	9	13.2 Plotting the object	46
5.1	Class slots	10	14 The “horizontalPointIZ” Class	46
5.2	Object creation	11	14.1 Object creation	48
5.3	Plotting the object	13	14.2 Plotting the object	50
6	The “sausageIZ” Class	14	14.3 The horizontalPointCMCIZ Class	50
6.1	Class slots	14	14.4 The horizontalPointISIZ Class	51
6.2	Object creation	15	14.5 The horizontalPointCVIZ Class	52
6.3	Plotting the object	16	15 The “horizontalLineIZ” Class	53
7	The “fullChainSawIZ” Class	17	15.1 Class slots	54
7.1	Object creation	18	15.2 Object creation	55
7.2	Plotting the object	19	15.3 Plotting the object	56
8	The “pointRelascopeIZ” Class	19	16 The “criticalHeightIZ” Class	57
8.1	Class slots	20	16.1 Object creation	58
8.2	Object creation	20	16.2 Plotting the object	59
8.3	Plotting the object	22	16.3 The “importanceCHSIZ” Class	59
9	The “perpendicularDistanceIZ” Class	23	16.3.1 Object creation	60
9.1	Class slots	24	16.3.2 Plotting the object	61
9.2	Object creation	25	16.4 The “antitheticICHSIZ” Class	61
9.3	Plotting the object	27	16.4.1 Object creation	62
9.4	Omnibus PDS	28	16.4.2 Plotting the object	63
9.4.1	Object creation	28	16.5 The “pairedAICHSIZ” Class	63
9.4.2	Plotting the object	29	16.5.1 Object creation	64
10	The “distanceLimitedIZ” Class	29	16.5.2 Plotting the object	65
10.1	Class slots	30	16.5.3 You’ve seen one	65
10.2	Object creation	30	17 Container Classes	65
10.3	Plotting the object	32	17.1 Class “izContainer”	65
11	The “distanceLimitedPDSIZ” Class	33	17.2 Class “downLogIZs”	66
11.1	Class slots	34	17.2.1 Class construction	66
11.2	Object creation	35	17.2.2 Plotting the object	69
11.3	Plotting the object	38	17.3 Class “standingTreeIZs”	69
11.4	The “omnibusDLPDSIZ” class	39	17.3.1 Class construction	70
11.4.1	Object creation	39	17.3.2 Plotting the object	73
			17.4 Container coercion	73
			Bibliography	75

1 Introduction

Inclusion zones in general are the area surrounding an object in which the sample point (e.g., a fixed-radius plot center) can land and sample the object. Therefore, they have a clearly defined area and perimeter. In addition, for probability proportional to size (PPS) methods, they depend on some attribute of the object, such as length in the case of a down log. This class and its subclasses bring together objects from the “ArealSampling” class and the “Stem” class, to define the more

useful subclasses corresponding to actual sampling methods for standing trees or down logs.

The “InclusionZone” object that will be defined through its subclasses will eventually instantiate an object that therefore contains both the inclusion zone and the stem itself. These components will be stored in separate slots in the object, so they can be accessed individually as needed, but for plotting and summary purposes, the object will be treated as the union of the two component objects that define the inclusion zone and stem.

Figure 1 presents an overview of the class hierarchy arrangement. Round-cornered boxes represent virtual classes. Container classes “downLogIZs” and “standingTreeIZs” are also shown; they will handle collections of objects of any of the “downLogIZ” or “standingTreeIZ” subclasses, respectively.




Figure 1: An overview of the “InclusionZone” class. “FixedArea” is not part of the class structure, but simply a subheading for the three protocol subclasses. The two container classes will be elaborated on later.

2 The “InclusionZone” Class

This is a virtual class which simply defines the main attributes of the subclasses. Note that this class is extremely basic, with two direct subclasses, much like the “Stem” class, for standing tree- and down log-based sampling methods.

The base class is defined with the slots...

```
R> showClass('InclusionZone')
```

```
Virtual Class "InclusionZone" [package "sampSurf"]
```

Slots:

Name:	description	units	bbox	spUnits	puaBlowup
Class:	character	character	matrix	CRS	numeric

Name:	puaEstimates	userExtra
Class:	list	ANY

Known Subclasses:

Class "downLogIZ", directly
 Class "standingTreeIZ", directly
 Class "standUpIZ", by class "downLogIZ", distance 2
 Class "chainSawIZ", by class "downLogIZ", distance 2
 Class "sausageIZ", by class "downLogIZ", distance 2
 Class "pointRelascopeIZ", by class "downLogIZ", distance 2
 Class "perpendicularDistanceIZ", by class "downLogIZ", distance 2
 Class "distanceLimitedIZ", by class "downLogIZ", distance 2
 Class "fullChainSawIZ", by class "downLogIZ", distance 3
 Class "omnibusPDSIZ", by class "downLogIZ", distance 3
 Class "distanceLimitedMCIZ", by class "downLogIZ", distance 3
 Class "distanceLimitedPDSIZ", by class "downLogIZ", distance 3
 Class "omnibusDLPDSIZ", by class "downLogIZ", distance 4
 Class "hybridDLPDSIZ", by class "downLogIZ", distance 4
 Class "circularPlotIZ", by class "standingTreeIZ", distance 2
 Class "horizontalPointIZ", by class "circularPlotIZ", distance 3
 Class "horizontalLineIZ", by class "standingTreeIZ", distance 2
 Class "criticalHeightIZ", by class "horizontalPointIZ", distance 4
 Class "importanceCHSIZ", by class "criticalHeightIZ", distance 5
 Class "antitheticICHSIZ", by class "importanceCHSIZ", distance 6
 Class "pairedAICHSIZ", by class "importanceCHSIZ", distance 6

2.1 Class slots

- *description*: Some descriptive text about this class.
- *units*: A character string specifying the units of measure. Legal values are “English” and “metric.”
- *bbox*: The bounding box enclosing the overall object and its inclusion zone. Since the inclusion zone may not include the entire object (as in the “standup” method for down logs), we require it here. Most of the time, it is actually redundant as the “SpatialPolygons” slot containing the inclusion zone in the subclasses will have this same information.

- *spUnits*: A valid string of class “CRS” denoting the spatial units coordinate system (“?CRS” for more information) as in package `sp`.
- *puaBlowup*: The per unit area blowup or expansion factor, based on an acre or hectare depending upon the units of measure.
- *puaEstimates*: A list of estimates for per unit area quantities associated with the “Stem” component of the object.
- *userExtra*: This can be anything else the user wants to associate with the object. Normally, it might be in the form of a `list` object, but can be anything. The user has complete control over this, it will not be used in any of the methods applied to the class, it is there for extra information storage as desired.

3 The “downLogIZ” Class

This is another small definitional step. It simply starts the bifurcation for subclasses that are related to “ArealSampling” classes for down logs. One slot is added in the process, that for a “downLog” object. Please note that this class is also *virtual*, and simply helps define the fact that its subclasses are “InclusionZone” classes for downed logs.

```
R> getClass('downLogIZ')
```

```
Virtual Class "downLogIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	downLog	description	units	bbox	spUnits
Class:	downLog	character	character	matrix	CRS

Name:	puaBlowup	puaEstimates	userExtra
Class:	numeric	list	ANY

```
Extends: "InclusionZone"
```

```
Known Subclasses:
```

```
Class "standUpIZ", directly
Class "chainSawIZ", directly
Class "sausageIZ", directly
Class "pointRelascopeIZ", directly
Class "perpendicularDistanceIZ", directly
Class "distanceLimitedIZ", directly
```

```

Class "fullChainSawIZ", by class "sausageIZ", distance 2
Class "omnibusPDSIZ", by class "perpendicularDistanceIZ", distance 2
Class "distanceLimitedMCIZ", by class "distanceLimitedIZ", distance 2
Class "distanceLimitedPDSIZ", by class "perpendicularDistanceIZ", distance 2
Class "omnibusDLPDSIZ", by class "distanceLimitedPDSIZ", distance 3
Class "hybridDLPDSIZ", by class "distanceLimitedPDSIZ", distance 3

```

4 The “standUpIZ” Class

Gove and Van Deusen (2011) recognize three main protocols for sampling down logs with fixed-area plots. The so-called “standup” method is probably the most commonly used. Basically, the standup method includes the log if the center of the large-end of the log lands within the sample plot. Therefore, the inclusion zone can be envisioned as centered on that point of the log. The subclass is defined as...

```
R> getClass('standUpIZ')
```

```
Class "standUpIZ" [package "sampSurf"]
```

Slots:

Name:	circularPlot	downLog	description	units	bbox
Class:	circularPlot	downLog	character	character	matrix
Name:	spUnits	puaBlowup	puaEstimates	userExtra	
Class:	CRS	numeric	list	ANY	

Extends:

```
Class "downLogIZ", directly
```

```
Class "InclusionZone", by class "downLogIZ", distance 2
```

It is seen to be a direct extension of the “downLogIZ” class, having added a slot for the “circularPlot” object.

4.1 Object creation

The constructor for the subclass takes a “downLog” object and a fixed-plot radius, the “circularPlot” object is created from the latter using the same units as those in the “downLog” object...

```
R> dl = downLog(species='red maple', logLen=10, buttDiam=10,
+               topDiam=2, center=c(x=3,y=2), logAngle=pi/4,
+               units='English', vol2wgt=30.6, wgt2carbon=0.5)
R> su = standUpIZ(dl, 5)
R> summary(su)
```

Object of class: standUpIZ

inclusion zone for "standup" method

InclusionZone...

Units of measurement: English
Per unit area blowup factor: 554.62315 per acre

Object bounding box...

	min	max
x	-5.5330166	6.5944595
y	-6.5349045	5.5944595

downLog component estimates...

Spatial ID: log:8i6r19vc
Number of logs: 554.62315 per acre
Volume: 1531.5143 cubic feet per acre
Surface area: 9878.5009 square feet per acre
Coverage area: 3142.8645 square feet per acre
Length: 5546.2315 feet per acre
Biomass (woody): 46864.337 per acre
Carbon content: 23432.169 per acre

standUpIZ...

use "summary" on the circularPlot slot for details

```
R> summary(su@circularPlot)
```

Object of class: circularPlot

fixed area circular plot

ArealSampling...

units of measurement: English

```
circularPlot...
  radius = 5 feet
  area = 78.539816 square feet (0.001803 acres)
  spatial units: NA
  spatial ID: su:o628cnb3
  location (plot center)...
    x coord: -0.53553391
    y coord: -1.5355339
  Number of perimeter points: 101 (closed polygon)
```

In the above example, the summary shows the extents of the object. Note that summaries of the “downLog” and “circularPlot” slots can easily be generated as shown.

4.2 Plotting the object

The `plot` generic function has also been extended to be able to handle plotting of the objects of the “standUpIZ” class. The arguments are again detailed in the help page, but here is a simple example...

```
R> plot(su, axes=TRUE, showPlotCenter=TRUE, cex=2, showNeedle=TRUE)
```

A couple things are worth noting in Figure 2. The overall bounding box includes the two objects, the inclusion zone (fixed-area plot) and the log, as is also shown in the above summary. The center of the plot is correctly aligned with the center of the large-end of the log. In addition, everything is relative to the location of the exact center of the log as defined in the “downLog” class. The correct juxtaposition of the inclusion zone is shown with regard to the log’s rotation angle (the `logAngle` slot in the object). Again this information is all self-contained within the object. For example, in this object, the log angle can be found simply as...

```
R> su@downLog@logAngle
```

```
[1] 0.78539816
```

```
R> identical(dl@logAngle, su@downLog@logAngle)
```

```
[1] TRUE
```





Figure 2: A “standUpIZ” object.

5 The “chainSawIZ” Class

A second, but probably less commonly used protocol is what Gove and Van Deusen (2011) call the “chainsaw” method. With this method, the intersection of the plot with the log defines a ‘sliver’ of the log which is measured for volume. They discuss three main sub-protocols for the implementation of this method. This class essentially allows implementation of all three, though only the sausage-based protocol is currently implemented as it is the most useful. The class extends “downLog” directly...

```
R> getClass('chainSawIZ')
```

```
Class "chainSawIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	circularPlot	sliver	bolt	downLog
Class:	circularPlot	SpatialPolygons	list	downLog
Name:	description	units	bbox	spUnits
Class:	character	character	matrix	CRS
Name:	puaBlowup	puaEstimates	userExtra	
Class:	numeric	list	ANY	

Extends:

Class "downLogIZ", directly

Class "InclusionZone", by class "downLogIZ", distance 2

wherein the following slots have been added...

5.1 Class slots

- *circularPlot*: An object of that class.
- *sliver*: A “SpatialPolygons” object representing the intersection (sliver) between the circular plot and the log.
- *bolt*: A `list` defining the ‘minimal bounding bolt’ within the log that fully encompasses the sliver. The slots in the `list` are defined as¹...
 - *rotBolt*: A matrix representation of the minimal bounding bolt.
 - *boltVol*: The bolt’s volume.
 - *sectVol*: The volume of the sliver section.
 - *area*: A vector containing the proportion of the bolt that the sliver encompasses, the bolt polygon area, and the sliver polygon area.
 - *boltLen*: The length of the bolt at its longest point, which is also the sliver section length.
 - *boltSA*: The bolt’s surface area.
 - *sectSA*: The sliver’s surface area.
 - *boltCA*: The bolt’s coverage area.
 - *sectCA*: The sliver’s coverage area.
 - *boltBms*: The bolt’s biomass content (can be NA).
 - *sectBms*: The sliver’s biomass content (can be NA).

¹See the `chainsawSliver` function for more details.

- *boltCarbon*: The bolt’s carbon content (can be NA).
- *sectCarbon*: The sliver’s carbon content (can be NA).
- *spBolt*: A “SpatialPolygons” object representing the minimal bounding bolt within the log.

5.2 Object creation

The constructor for the subclass takes a “downLog” object, a fixed-plot radius, and a center point for the fixed-radius plot...

```
R> cs = chainSawIZ(dl, 2, c(x=7.8, y=3.9), runQuiet=FALSE)
```

```
Percentage sliver is of bolt area = 18.075158
Bolt volume (not expanded) = 0.042612638
Section/sliver volume (not expanded) = 0.0077023016
```

```
R> summary(cs)
```

```
Object of class: chainSawIZ
```

```
-----
inclusion zone for "chainsaw" method
-----
```

```
InclusionZone...
```

```
Units of measurement: English
```

```
Per unit area blowup factor: 3466.3947 per acre
```

```
Object bounding box...
```

```
      min      max
x -0.83016173 9.8000000
y -1.83016173 5.8997483
```

```
downLog component estimates...
```

```
Spatial ID: log:8i6r19vc
```

```
Number of logs: 3466.3947 per acre
```

```
Volume: 26.699217 cubic feet per acre
```

```
Surface area: 427.35022 square feet per acre
```

```
Coverage area: 135.60665 square feet per acre
```

```
Length: 3051.8683 feet per acre
```

```
Biomass (woody): 816.99604 per acre
Carbon content: 408.49802 per acre
The above estimates are based on the expanded sliver portion.
```

```
The following are unexpanded...
Sliver area is 0.18075158 of bounding bolt
Total log volume: 2.7613602 cubic feet
  Bounding bolt volume: 0.042612638 cubic feet
  Sliver volume: 0.0077023016 cubic feet
Total log surface area: 17.811195 square feet
  Bounding bolt surface area: 0.68206195 square feet
  Sliver surface area: 0.12328378 square feet
Total log coverage area: 5.6666667 square feet
  Bounding bolt coverage area: 0.2164317 square feet
  Sliver coverage area: 0.039120372 square feet
Total log length: 10 feet
  Bounding bolt length: 0.8804157 feet
Total log biomass: 84.497622
  Bounding bolt biomass: 1.3039467
  Sliver biomass: 0.23569043
Total log carbon: 42.248811
  Bounding bolt carbon: 0.65197336
  Sliver carbon: 0.11784521
```

```
chainSawIZ...
```

```
  use "summary" on the circularPlot slot for sample plot details
```

The `summary` method shows a bit more information about the resulting object than with other protocols. Most importantly, it shows information about the sliver size and volume, etc., and the minimal bounding bolt’s size with respect to the entire log. We can see from this example, that we truly must have just cut a little sliver off, since its volume is so small. However, in the next example, we take a good chunk of the log in the plot intersection...

```
R> cs2 = chainSawIZ(dl, plotRadius=3, c(x=2, y=2), runQuiet=FALSE)
```

```
Percentage sliver is of bolt area = 97.811679
Bolt volume (not expanded) = 1.8407255
Section/sliver volume (not expanded) = 1.8004445
```

The constructor was requested to print the necessary information for comparison, and it will be verified by the graphics below.

5.3 Plotting the object

The `plot` generic function has also been extended to be able to handle plotting of the objects of the “chainSawIZ” class. The arguments are again detailed in the help page, but here is a simple example...

```
R> plot(cs, axes=TRUE, showNeedle=TRUE, showPlotCenter=TRUE)
R> plot(cs2, add=TRUE, showPlotCenter=TRUE, showLog=FALSE, izColor=NA)
```




Figure 3: “chainsawIZ” objects comparison.

Figure 3 presents a comparison of the two “chainSawIZ” objects created above, using the same log for reference. As mentioned above, the second object takes a much larger slice of the log for an estimate of volume than the first. It is also worth noting that the first example shows an intersection where the log’s ‘needle’ is not encountered. This would therefore not qualify as falling into the sausage-shaped inclusion zone for the overall log, unless it also intersected the end of the log (see [Gove and Van Deusen \(2011\)](#) for details). In the figure, the minimal bounding bolts are

delineated by the dotted lines, and the slivers are clearly seen in the intersection, also shown as dashed.

6 The “sausageIZ” Class

Another method, which allows the log to be sampled if any part of it’s “needle” falls inside the circular fixed-area plot is called the “sausage” method by Gove and Van Deusen (2011). It is a direct subclass of “downLogIZ”...

```
R> getClass('sausageIZ')
```

```
Class "sausageIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	sausage	radius	area	perimeter
Class:	matrix	numeric	numeric	SpatialPolygons

Name:	pgSausageArea	downLog	description	units
Class:	numeric	downLog	character	character

Name:	bbox	spUnits	puaBlowup	puaEstimates
Class:	matrix	CRS	numeric	list

Name:	userExtra
Class:	ANY

```
Extends:
```

```
Class "downLogIZ", directly
```

```
Class "InclusionZone", by class "downLogIZ", distance 2
```

```
Known Subclasses: "fullChainSawIZ"
```

wherein the following slots have been added...

6.1 Class slots

- *sausage*: A matrix representation of the sausage inclusion zone in homogeneous coordinates. This can be manipulated and plotted as desired for easy access to the inclusion zone where

needed.

- *radius*: The radius for the fixed-area plot that determines the sausage inclusion zone area.
- *area*: The exact area of the inclusion zone.
- *perimeter*: This is the inclusion zone perimeter as a “SpatialPolygons” object.
- *pgSausageArea*: This is the area of the sausage inclusion zone as calculated from the polygon in the `perimeter` slot using the “SpatialPolygons” object. As such, it is an approximation of the true area of the inclusion zone, which is given in the `area` slot. This just enables us to see how close the graphic representation is to the real area.

6.2 Object creation

The constructor for the subclass takes a “downLog” object and a fixed-plot radius, much like the “standUpIZ” class. From this the inclusion zone is determined...

```
R> sa = sausageIZ(dl, 5)
R> summary(sa)
```

```
Object of class: sausageIZ
```

```
-----
inclusion zone for downed log "sausage" sampling method
-----
```

```
InclusionZone...
```

```
Units of measurement: English
```

```
Per unit area blowup factor: 243.97919 per acre
```

```
Object bounding box...
```

```
      min      max
x -5.5348916 11.535534
y -6.5348916 10.535534
```

```
downLog component estimates...
```

```
Spatial ID: log:8i6r19vc
```

```
Number of logs: 243.97919 per acre
```

```
Volume: 673.71443 cubic feet per acre
```

```
Surface area: 4345.5609 square feet per acre
```

```
Coverage area: 1382.5488 square feet per acre
```

```
Length: 2439.7919 feet per acre
```

```
Biomass (woody): 20615.662 per acre
```

Carbon content: 10307.831 per acre

sausageIZ...

```
Spatial ID: saus:o47x63py
radius = 5 feet
area = 178.53982 square feet (0.004099 acres)
Number of perimeter points: 101 (closed polygon)
```

```
R> sa@pgSausageArea
```

```
[1] 178.48489
```

We note from the above that there is a little bias in the area of the inclusion zone when computed from the “SpatialPolygons” object. This is small, but shows the approximate nature of the inclusion zone perimeter. Using more points to define the half-circles on each end of the zone allows this area estimate to converge to the actual area. Using too few points obviously results in larger bias. This should be kept in mind when constructing grids for sampling surface simulations eventually with these objects, because the perimeter will determine what grid cell centers are within the inclusion zone, and hence get assigned a surface attribute value.

6.3 Plotting the object

The `plot` generic function has also been extended to be able to handle plotting of the objects of the “sausageIZ” class. The arguments are again detailed in the help page, but here is a simple example...

```
R> plot(sa, axes=TRUE, showLogCenter=TRUE, cex=2, showNeedle=TRUE)
R> dl2 = downLog(species='white pine', logLen=4, buttDiam=6,
+               topDiam=0, center=c(x=1,y=4), logAngle=3*pi/4, units='English'
+               )
R> sa2 = sausageIZ(dl2, 5)
R> plot(sa2, add=TRUE, izCol=NA)
R> plot(su@circularPlot@perimeter, lty='dashed', border='grey50', add=TRUE)
```

Figure 4 illustrates the sausage inclusion zones for two down logs. In the case of the longest log, the standup inclusion zone perimeter is shown for comparison.

One other thing to keep in mind under sausage sampling is that the log and inclusion zone centers coincide. Therefore, plotting the log center will identify them both using `showLogCenter=TRUE`;




Figure 4: “sausageIZ” objects with “standUpIZ” perimeter for comparison.

using `showPlotCenter=TRUE` does nothing at present. If you really want to also display the plot center, it can always be accessed via the `downLog` slot in the object itself: the `location` slot in this object is an object of class “SpatialPoints” and therefore can be accessed as the inclusion zone plot center.

7 The “fullChainSawIZ” Class

This class incorporates the inclusion zone for the full chain saw method [Gove and Van Deusen \(2011\)](#). The inclusion zone itself is a direct subclass of the “sausageIZ” class discussed in §6 and it adds no new slots. It is given its own class for method dispatch on signature arguments allowing differentiation between this and the sausage method.

```
R> getClass('fullChainSawIZ')
```

Class "fullChainSawIZ" [package "sampSurf"]

Slots:

Name:	sausage	radius	area	perimeter
Class:	matrix	numeric	numeric	SpatialPolygons

Name:	pgSausageArea	downLog	description	units
Class:	numeric	downLog	character	character

Name:	bbox	spUnits	puaBlowup	puaEstimates
Class:	matrix	CRS	numeric	list

Name:	userExtra
Class:	ANY

Extends:

Class "sausageIZ", directly

Class "downLogIZ", by class "sausageIZ", distance 2

Class "InclusionZone", by class "sausageIZ", distance 3

7.1 Object creation

The following will produce an inclusion zone that is exactly the same as that for the sausage sampling example in §6...

```
R> fcs = fullChainSawIZ(dl, 5)
R> summary(fcs)
```

Object of class: fullChainSawIZ

Inclusion zone for "fullChainSaw" sampling method

InclusionZone...

Units of measurement: English

Per unit area blowup factor: 243.97919 per acre

Object bounding box...

	min	max
x	-5.5348916	11.535534

```
y -6.5348916 10.535534
```

```
downLog component estimates...
```

```
Spatial ID: log:8i6r19vc
Number of logs: 243.97919 per acre
Volume: NA cubic feet per acre
Surface area: NA square feet per acre
Coverage area: NA square feet per acre
Length: NA feet per acre
Biomass (woody): NA per acre
Carbon content: NA per acre
```

```
sausageIZ...
```

```
Spatial ID: fcs:uy61i30g
radius = 5 feet
area = 178.53982 square feet (0.004099 acres)
Number of perimeter points: 101 (closed polygon)
```

7.2 Plotting the object

Similarly, plotting the object will result in the same inclusion zone as shown in Figure 4.

8 The “pointRelascopeIZ” Class

This class combines the usual information from an individual “downLog” object along with a given “pointRealscope” areal sampling object to create an inclusion zone for the point relascope sampling method (Gove et al. 1999, Gove et al. 2001). Recall that the inclusion area is proportional to the squared-length, so both objects are required in the class. It is a direct subclass of “downLogIZ”...

```
R> getClass('pointRelascopeIZ')
```

```
Class "pointRelascopeIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	prs	dualCircle	radius	area
Class:	pointRelascope	matrix	numeric	numeric
Name:	perimeter	pgDualArea	dualCenters	downLog

Class:	SpatialPolygons	numeric	matrix	downLog
Name:	description	units	bbox	spUnits
Class:	character	character	matrix	CRS
Name:	puaBlowup	puaEstimates	userExtra	
Class:	numeric	list	ANY	

Extends:

Class "downLogIZ", directly

Class "InclusionZone", by class "downLogIZ", distance 2

8.1 Class slots

The following slots have been added to this subclass...

- *prs*: An object of class “pointRelascope” that furnishes the information about the point relascope method.
- *dualCircle*: A matrix representation of the inclusion zone in homogeneous coordinates. This can be manipulated and plotted as desired for easy access to the inclusion zone where needed.
- *radius*: The radius in the appropriate units of each of the dual circles comprising the inclusion zone.
- *area*: The exact area of the inclusion zone.
- *perimeter*: This is the inclusion zone perimeter as a “SpatialPolygons” object.
- *pgDualArea*: This is the area of the inclusion zone as calculated from the polygon in the **perimeter** slot using the “SpatialPolygons” object. As such, it is an approximation of the true area of the inclusion zone, which is given in the **area** slot. This just enables us to see how close the graphic representation is to the real area.
- *dualCenters*: The center points of the dual circles stored as a matrix (not in homogeneous form).

8.2 Object creation

The constructor for the subclass takes a “downLog” object and an object of class “pointRelascope”. From this the inclusion zone is determined...

```
R> (rw.angle = .StemEnv$rad2Deg(2*atan(1/4)))
```

```
[1] 28.072487
```

```
R> prs4 = pointRelascope(rw.angle, units='English')
```

```
R> iz.prs = pointRelascopeIZ(dl, prs4)
```

```
R> iz.prs
```

```
Object of class: pointRelascopeIZ
```

```
-----  
inclusion zone for down log point relascope sampling method  
-----
```

```
InclusionZone...
```

```
Units of measurement: English
```

```
Per unit area blowup factor: 62.908019 per acre
```

```
Object bounding box...
```

```
      min      max
```

```
x -14.253728 20.253728
```

```
y -15.253728 19.253728
```

```
downLog component estimates...
```

```
Spatial ID: log:8i6r19vc
```

```
Number of logs: 62.908019 per acre
```

```
Volume: 173.7117 cubic feet per acre
```

```
Surface area: 1120.467 square feet per acre
```

```
Coverage area: 356.47878 square feet per acre
```

```
Length: 629.08019 feet per acre
```

```
Biomass (woody): 5315.5781 per acre
```

```
Carbon content: 2657.789 per acre
```

```
pointRelascopeIZ...
```

```
Spatial ID: prs:0982vuhd
```

```
dual circle radius = 10.625 feet
```

```
area = 692.43954 square feet (0.0159 acres)
```

```
Number of perimeter points: 201 (closed polygon)
```

```
R> iz.prs@pgDualArea
```

```
[1] 692.15325
```

Again, as in the sausage method, we have relatively good agreement in this example between the actual area of the inclusion zone and that calculated from the “SpatialPolygons” object. And again, the fact that the latter can be adjusted through the number of points in each dual circle should be kept in mind when running simulations (see `?pointRelascopeIZ`). This is a very small angle, and draws in logs from far away. Likewise, it will encompass a good number of grid cells in the final sampling surface simulation; therefore, it makes sense to have the polygon and true area agree well, so we are not excluding grid cells. If we try to cut the number of points in each circle down we see that the area does not agree as well...

```
R> iz.prs = pointRelascopeIZ(dl, prs4, nptsCircle=50)
R> c(iz.prs@area, iz.prs@pgDualArea)
```

```
[1] 692.43954 691.27141
```

This is something to be kept in mind, the smaller relascope angle, the more points are required on the perimeter, or some bias from the approximation to the inclusion zone polygon could show up in the simulations.

8.3 Plotting the object

The `plot` generic function has also been extended to be able to handle plotting of the objects of the “pointRelascopeIZ” class. The arguments are again detailed in the help page (`methods?plot`), a simple example follows...

```
R> plot(iz.prs, axes=TRUE, showDualCenters=TRUE, showLogCenter=TRUE,
+       cex=2, showNeedle=TRUE)
R> (rw.angle = .StemEnv$rad2Deg(2*atan(1/2)))
```

```
[1] 53.130102
```

```
R> prs2 = pointRelascope(rw.angle, units='English')
R> iz.prs = pointRelascopeIZ(dl, prs2)
R> plot(perimeter(iz.prs), add=TRUE, lty='dashed', border=.StemEnv$izBorderColor)
```




Figure 5: “pointRelascopeIZ” objects with different angles for comparison. Also shown are the dual circle centers for the smaller angle (larger inclusion zone).

9 The “perpendicularDistanceIZ” Class

This class combines the usual information from an individual “downLog” object along with a given “perpendicularDistance” areal sampling object to create an inclusion zone for the perpendicular distance sampling method (Williams and Gove 2003, Williams et al. 2005, Ducey et al. 2008). Recall that the inclusion area is proportional to some function of diameter along the entire length, so both objects are required in the class. It is a direct subclass of “downLogIZ”...

```
R> getClass('perpendicularDistanceIZ')
```

```
Class "perpendicularDistanceIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	pds	izPerim	area
Class:	perpendicularDistance	matrix	numeric
Name:	perimeter	pgArea	pdsType
Class:	SpatialPolygons	numeric	character
Name:	downLog	description	units
Class:	downLog	character	character
Name:	bbox	spUnits	puaBlowup
Class:	matrix	CRS	numeric
Name:	puaEstimates	userExtra	
Class:	list	ANY	

Extends:

Class "downLogIZ", directly

Class "pdsIZNull", directly

Class "InclusionZone", by class "downLogIZ", distance 2

Known Subclasses:

Class "omnibusPDSIZ", directly

Class "distanceLimitedPDSIZ", directly

Class "omnibusDLPDSIZ", by class "distanceLimitedPDSIZ", distance 2

Class "hybridDLPDSIZ", by class "distanceLimitedPDSIZ", distance 2

9.1 Class slots

The following slots have been added to this subclass...

- *pds*: An object of class “perpendicularDistance” that furnishes the information about the perpendicular distance method.
- *izPerim*: A matrix representation of the inclusion zone in homogeneous coordinates. This can be manipulated and plotted as desired for easy access to the inclusion zone where needed.
- *area*: The exact area of the inclusion zone.
- *perimeter*: This is the inclusion zone perimeter as a “SpatialPolygons” object.
- *pgArea*: This is the area of the inclusion zone as calculated from the polygon in the **perimeter** slot using the “SpatialPolygons” object. As such, it is an approximation of the true area of

the inclusion zone, which is given in the **area** slot. This just enables us to see how close the graphic representation is to the real area.

- *pdsType*: Specifies the type of perpendicular distance sampling used: volume, surface or coverage area.

9.2 Object creation

As noted above, the **pdsType** slot stores the type of PDS sample we have used in the sense of sampling with probability proportional to either volume, surface area or coverage area. In what follows, we demonstrate only sampling with PP to volume, which is the default. However, if one would like to use either of the other two protocols, simply include the **pdsType** argument in the constructor, with one of the following as the specification to this argument...

```
R> .StemEnv$pdsTypes
```

```
[1] "volume"      "surfaceArea" "coverageArea"
```

The constructor for the subclass takes a “downLog” object and an object of class “perpendicularDistance”. From this the inclusion zone is determined...

```
R> pdsEng = perpendicularDistance(kpds=10, units='English')
R> iz.pdsv = perpendicularDistanceIZ(dl, pdsEng)
R> c(iz.pdsv@area, iz.pdsv@pgArea)
```

```
[1] 55.227204 55.212106
```

```
R> iz.pdsv
```

```
Object of class: perpendicularDistanceIZ
```

```
-----
inclusion zone for down log perpendicular distance sampling
-----
```

```
InclusionZone...
```

```
Units of measurement: English
```

```
Per unit area blowup factor: 788.74172 per acre
```

```
Object bounding box...
      min      max
x -4.3922031 6.6898007
y -5.3922031 5.6898007

downLog component estimates...
Spatial ID: log:8i6r19vc
Number of logs: 788.74172 per acre
Volume: 2178 cubic feet per acre
Surface area: 14048.432 square feet per acre
Coverage area: 4469.5364 square feet per acre
Length: 7887.4172 feet per acre
Biomass (woody): 66646.8 per acre
Carbon content: 33323.4 per acre

perpendicularDistanceIZ...
PDS type: volume
Spatial ID: pds:t2ce594r
area = 55.227204 square feet (0.001268 acres)
Number of perimeter points: 43 (closed polygon)
```

First, we create an “ArealSampling” object of class “perpendicularDistance”, and subsequently create the inclusion zone object for the respective log. The area comparison between the theoretically correct area of the inclusion zone and that based on the polygon approximation is shown next. Surprisingly, the polygon approximation is quite good as it is based on the taper data in the “downLog” object. This is something to be kept in mind for simulations, if too few points are used to determine the taper, the inclusion zone can be poorly determined because it uses these taper points directly. So if a set of simulations produces some measurable bias, poor taper data restricting the underlying grid cells in the final sampling surface may be the cause under PDS. In the above example the taper slot in the log had 21 taper measurements, so the inclusion zone polygon has...

```
R> nrow(dl@taper)*2+1
```

```
[1] 43
```

perimeter points in the closed polygon (first and last point are repeated).

9.3 Plotting the object

The `plot` generic function has also been extended to be able to handle plotting of the objects of the “perpendicularDistanceIZ” class. The arguments are again detailed in the help page (`methods?plot`), a simple example follows...

```
R> plot(iz.pdsv, axes=TRUE, showLogCenter=TRUE, cex=2, showNeedle=TRUE)
R> pdsEng2 = perpendicularDistance(kpds=5, units='English')
R> iz.pdsv2 = perpendicularDistanceIZ(d1, pdsEng2)
R> plot(perimeter(iz.pdsv2), add=TRUE, lty='dashed', border=.StemEnv$izBorderColor)
```




Figure 6: “perpendicularDistanceIZ” objects with different K PDS values for comparison.

9.4 Omnibus PDS

Omnibus PDS is described by Ducey et al. (2008). It allows us to get estimates of attributes other than the one of the three primary selection attributes of volume, surface area or coverage area. The “omnibusPDSIZ” class definition is *exactly* the same as the “perpendicularDistanceIZ” class. In fact it is a subclass of the latter that adds no new slots, so we can refer directly to the information in the last section for the class definition.

9.4.1 Object creation

Object creation is also the same for omnibus. This is because the inclusion zone is exactly the same. However, the eventual sampling surface inside the inclusion zone will be variable in height, so there is no one overall estimate of the quantities of interest that can be calculated. This is because the estimates for each point within the inclusion zone rely on some function of diameter at the perpendicular. More will be covered on this in “*The InclusionZoneGrid Class*” vignette.

```
R> iz.opdsv = omnibusPDSIZ(dl, pdsEng)
R> iz.opdsv
```

```
Object of class: omnibusPDSIZ
```

```
-----
inclusion zone for down log omnibus perpendicular distance sampling
-----
```

```
InclusionZone...
```

```
Units of measurement: English
```

```
Per unit area blowup factor: 788.74172 per acre
```

```
Object bounding box...
```

```
      min      max
x -4.3922031 6.6898007
y -5.3922031 5.6898007
```

```
downLog component estimates...
```

```
Spatial ID: log:8i6r19vc
```

```
Number of logs: NA per acre
```

```
Volume: NA cubic feet per acre
```

```
Surface area: NA square feet per acre
```

```
Coverage area: NA square feet per acre
```

```
Length: NA feet per acre
```

```
Biomass (woody): NA per acre
```

Carbon content: NA per acre

omnibusPDSIZ...

PDS type: volume

Spatial ID: opds:xq14901i

area = 55.227204 square feet (0.001268 acres)

Number of perimeter points: 43 (closed polygon)

Note particularly that the “downLog” component estimates are all NA reflecting the above point concerning the variable sampling surface within the inclusion zone.

9.4.2 Plotting the object

A plot of this object would look *exactly* like the wide zone in Figure 6, so there is no need to repeat that here.

10 The “distanceLimitedIZ” Class

Distance limited sampling comes in two forms. The first (DLS) applies normal field protocols under this method. The second, distance limited Monte Carlo Sampling (DLMCS), uses crude Monte Carlo for the field protocol (Gove et al., 2012). The inclusion zones are exactly the same for each protocol, it is only the field measurements that differ—much like the two “flavors” of PDS and distance limited PDS presented below. Therefore, here we simply show how to create inclusion zones and what they look like. Basically, DLS is a probability proportional to length sampling method that invokes a perpendicular distance limit, creating a rectangular inclusion zone that has the same length as the log. It is also relevant because it plays a part in distance limited PDS (both canonical and omnibus), which will be discussed in the next section.

```
R> getClass('distanceLimitedIZ')
```

```
Class "distanceLimitedIZ" [package "sampSurf"]
```

Slots:

Name:	dls	izPerim	area	perimeter
Class:	distanceLimited	matrix	numeric	SpatialPolygons
Name:	pgArea	downLog	description	units

```

Class:          numeric          downLog          character          character

Name:           bbox             spUnits         puaBlowup         puaEstimates
Class:          matrix           CRS              numeric          list

Name:           userExtra
Class:          ANY

Extends:
Class "downLogIZ", directly
Class "dlsIZNull", directly
Class "InclusionZone", by class "downLogIZ", distance 2

Known Subclasses: "distanceLimitedMCIZ"

```

10.1 Class slots

The following slots have been added to this subclass...

- *dls*: An object of class “distanceLimited” that furnishes the information about the distance limited “ArealSampling” method.
- *izPerim*: A matrix representation of the inclusion zone in homogeneous coordinates. This can be manipulated and plotted as desired for easy access to the inclusion zone where needed.
- *area*: The exact area of the inclusion zone.
- *perimeter*: This is the inclusion zone perimeter as a “SpatialPolygons” object.
- *pgArea*: This is the area of the inclusion zone as calculated from the polygon in the **perimeter** slot using the “SpatialPolygons” object. As such, it is an approximation of the true area of the inclusion zone, which is given in the **area** slot. This just enables us to see how close the graphic representation is to the real area.

The “distanceLimitedMCIZ” class for DLMCS has exactly the same slots as above.

10.2 Object creation

Object creation is with its own constructor as usual and is the same for either field protocol, we use the DLMCS version as an example; to generate an object of class “distanceLimitedIZ”, just use **distanceLimitedIZ** in place of the constructor below...

```
R> dlsEng = distanceLimited(6, units='English')
R> iz.dlmcs = distanceLimitedMCIZ(dl, dls=dlsEng)
R> iz.dlmcs
```

```
Object of class: distanceLimitedMCIZ
```

```
-----
inclusion zone for down log DLMC sampling
-----
```

```
InclusionZone...
```

```
Units of measurement: English
Per unit area blowup factor: 3630 per acre
```

```
Object bounding box...
```

```
      min      max
x -4.7781746 10.7781746
y -5.7781746  9.7781746
```

```
downLog component estimates...
```

```
Spatial ID: log:8i6r19vc
Number of logs: 363 per acre
Volume: NA cubic feet per acre
Surface area: NA square feet per acre
Coverage area: NA square feet per acre
Length: 3630 feet per acre
Biomass (woody): NA per acre
Carbon content: NA per acre
(Note: NAs signify location-dependent attributes.)
```

```
distanceLimitedMCIZ...
```

```
Spatial ID: dlmc:7ozk82h3
distance limit = 6 feet
area = 120 square feet (0.002755 acres)
Number of perimeter points: 5 (closed polygon)
```

Note that we do not need to explicitly specify the units as ‘English’ in the constructor function because it takes the units from the “downLog” and “distanceLimited” objects passed. Also note that most of the estimates are NA, reflecting the variable surface height for these attributes. This would not be the case under DLS (`distanceLimitedIZ`), where the usual constant estimates apply creating a flat surface (Gove et al., 2012).

10.3 Plotting the object

The `plot` generic function has also been extended to be able to handle plotting of the objects of the “distanceLimitedIZ” and “distanceLimitedMCIZ” classes. The arguments are again detailed in the help page (`methods?plot`), a simple example follows...

```
R> plot(iz.dlmcs, axes=TRUE, showLogCenter=TRUE, cex=2, showNeedle=TRUE)
R> dlsEng2 = distanceLimited(3, units='English')
R> iz.dlmcs2 = distanceLimitedMCIZ(dl, dls=dlsEng2)
R> plot(perimeter(iz.dlmcs2), add=TRUE, lty='dashed', border=.StemEnv$izBorderColor)
```




Figure 7: “distanceLimitedMCIZ” object.

Note that in Figure 7 we have plotted two inclusion zones of different widths for comparison. Again, the inclusion zones for DLS using `distanceLimitedIZ`, would look exactly the same.

11 The “distanceLimitedPDSIZ” Class

Distance limited PDS (DLPDS) was initially developed by [Ducey et al. \(2013\)](#). It established a distance limit, beyond which we truncate the PDS inclusion zone, effectively limiting the search distance for logs of any size. This class combines the usual information from an individual “down-Log” object along with “perpendicularDistance” and “distanceLimited” areal sampling objects, to create an inclusion zone. The inclusion zone thus may have both PDS and DLS components to it. Notice we say it *may* have components of both forms included, but does not have to, there are three possibilities: (i) the inclusion zone is all PDS, (ii) the inclusion zone is all DLS, or (iii) it is a combination of the two. Which of the three are true for a given log depends on the distance limit chosen and the size of the log, which will determine whether there is any limiting diameter separating the two sampling types.

```
R> showClass('distanceLimitedPDSIZ')
```

```
Class "distanceLimitedPDSIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	dls	dlsDiameter	pdsPart
Class:	distanceLimited	numeric	pdsIZNull
Name:	dlsPart	pdsFull	pds
Class:	dlsIZNull	pdsIZNull	perpendicularDistance
Name:	izPerim	area	perimeter
Class:	matrix	numeric	SpatialPolygons
Name:	pgArea	pdsType	downLog
Class:	numeric	character	downLog
Name:	description	units	bbox
Class:	character	character	matrix
Name:	spUnits	puaBlowup	puaEstimates
Class:	CRS	numeric	list
Name:	userExtra		
Class:	ANY		

```
Extends:
```

```
Class "perpendicularDistanceIZ", directly
```

Class "downLogIZ", by class "perpendicularDistanceIZ", distance 2
 Class "pdsIZNull", by class "perpendicularDistanceIZ", distance 2
 Class "InclusionZone", by class "perpendicularDistanceIZ", distance 3

Known Subclasses: "omnibusDLPDSIZ", "hybridDLPDSIZ"

Note that this class is a direct subclass of “perpendicularDistanceIZ”.

11.1 Class slots

The following slots have been added to this subclass...

- *dls*: An object of class “distanceLimited” that furnishes the information about the distance limited “ArealSampling” method.
- *dlsDiameter*: The limiting diameter where the delineation (if any) occurs between PDS and DLS protocols within the log (see below for an example and calculation).
- *pdsPart*: Either a fully valid “perpendicularDistanceIZ” (or subclass, i.e., “omnibusPDSIZ” object) or NULL if no component of this class exists for the log.
- *dlsPart*: Either a fully valid “distanceLimitedIZ” (or subclass, i.e., “distanceLimitedMCIZ” object) or NULL if no component of this class exists for the log.
- *pdsFull*: This holds a fully valid “perpendicularDistanceIZ” (or subclass, i.e., “omnibusPDSIZ” object) delineating the full PDS zone as it would appear if the entire log were treated as a PDS sampling object. Note that it can be useful to compare this to the DLPDS object graphically.
- *pds*: An object of class “perpendicularDistance” that furnishes the information about the perpendicular distance method.
- *izPerim*: A matrix representation of the inclusion zone in homogeneous coordinates. This can be manipulated and plotted as desired for easy access to the inclusion zone where needed.
- *area*: The exact area of the inclusion zone.
- *perimeter*: This is the inclusion zone perimeter as a “SpatialPolygons” object.
- *pgArea*: This is the area of the inclusion zone as calculated from the polygon in the **perimeter** slot using the “SpatialPolygons” object. As such, it is an approximation of the true area of the inclusion zone, which is given in the **area** slot. This just enables us to see how close the graphic representation is to the real area.
- *pdsType*: Specifies the type of perpendicular distance sampling used: volume, surface or coverage area.

Now we can more fully look at the three component possibilities mentioned above with respect to the fields in the object...

- (i) In the case where the inclusion zone is just a regular PDS object, we will have: **pdsPart** and **dlsPart** both NULL, and **pdsFull** a redundant copy of the full PDS portion of the object itself.
- (ii) If the inclusion zone is all DLS, with no PDS component, then the overall object will ‘act like’ a “distanceLimitedIZ” object. The **pdsPart** slot will be NULL, while the **dlsPart** slot will carry a “distanceLimitedIZ” object and the **pdsFull** slot will again hold a full PDS inclusion zone class object (which is not applicable in this case, but is still retained for possible comparison, see next point).
- (iii) Finally, if both components are involved in the log’s inclusion zone, then the overall object contains the compound inclusion zone information. Both the **pdsPart** and **dlsPart** slots will contain the respective objects making up their components of the class, and the **pdsFull** slot will again hold a full PDS inclusion zone class object *as if* PDS were used on the entire log. In this case, for example, we could plot either the **pdsPart** or **dlsPart** objects to show the delineation between the two zones, and we could also plot the comparable PDS object for the whole log by plotting the object in the **pdsFull** slot.

It is important to realize in the above, that the slots containing the component parts (if they exist) are valid objects of the correct type in and of themselves. Thus, for example, they also contain the portion of the log that corresponds to the component part of the overall inclusion zone and will piece together to form the whole.

11.2 Object creation

Object creation is with its own constructor as usual, though note that we need both types of “ArealSampling” objects to define the two regions...

```
R> dlsEng3 = distanceLimited(2, units='English')
R> iz.dlpds = distanceLimitedPDSIZ(d1, pds=pdsEng2, dls=dlsEng3)
R> iz.dlpds
```

```
Object of class: distanceLimitedPDSIZ
```

```
-----
inclusion zone for down log distance limited PDS
-----
```

InclusionZone...

Units of measurement: English

Per unit area blowup factor: NA per acre

Object bounding box...

min max

x -1.9497475 6.6126673

y -2.9497475 5.6126673

downLog component estimates...

Spatial ID: log:8i6r19vc

Number of logs: 7053.8319 per acre

Volume: 9496.6655 cubic feet per acre

Surface area: 59010.92 square feet per acre

Coverage area: 18775.168 square feet per acre

Length: 31798.847 feet per acre

Biomass (woody): 290597.96 per acre

Carbon content: 145298.98 per acre

distanceLimitedPDSIZ...

PDS type: volume

Spatial ID: dlpds:30a2f4ju

area = 25.755564 square feet (0.0005913 acres)

Number of perimeter points: 37 (closed polygon)

(The above summary is for the entire DLPDS region)

distanceLimitedPDSIZ details...

distance limit = 2 feet

limiting diameter = 0.71364965 feet (8.564 in)

distance limited component available = TRUE

PDS component available = TRUE

Summaries of individual DLPDS components can be viewed seperately

```
R> class(iz.dlpds@pdsPart)
```

```
[1] "perpendicularDistanceIZ"
```

```
attr(,"package")
```

```
[1] "sampSurf"
```

```
R> class(iz.dlpds@dlsPart)
```

```
[1] "distanceLimitedIZ"
attr(,"package")
[1] "sampSurf"
```

The summary above shows the information for the overall object under the “perpendicularDistanceIZ” section of the report. Following this, in the “distanceLimitedPDSIZ” section, is more specific information about the current class’ extension. For example, the limiting diameter is listed along with information indicating whether or not the `pdsPart` and `dlsPart` slots are available within the object.

Note that the limiting diameter is determined differently under each of the different PDS PPS variables; *viz.*, its formula in feet or meters for each is...

$$d_l^* = \sqrt{\frac{4 * D_l}{\pi K_{PDS}}} \quad \text{PP volume}$$

$$d_l^* = \frac{D_l}{\pi K_{PDS}} \quad \text{PP Surface Area}$$

$$d_l^* = \frac{D_l}{K_{PDS}} \quad \text{PP Coverage Area}$$

where D_l is the distance limit in feet or meters. In the above example, the limiting diameter in inches is calculated as...

```
R> sqrt(4*dlsEng3@distanceLimit/(pi*pdsEng2@kpds))*12
```

```
[1] 8.5637958
```

which matches what was shown in the report above. Therefore, since the above diameter is between the butt (10 in) and top (2 in) diameters, both methods are present in the log. If we used a larger limiting distance then we would get a case where the entire log is sampled with PDS...

```
R> sqrt(4*dlsEng2@distanceLimit/(pi*pdsEng2@kpds))*12
```

```
[1] 10.488465
```

Likewise, the following shows the distance limit we would have to use in order for the entire log to be considered under only DLMCS...

```
R> iz.dlpds@downLog@topDiam^2 * pdsEng2@kpds*pi/4
```

```
[1] 0.10908308
```

11.3 Plotting the object

The `plot` generic function has also been extended to be able to handle plotting of the objects of the “distanceLimitedPDSIZ” class. The arguments are again detailed in the help page (`methods?plot`), a simple example follows...

```
R> plot(perimeter(iz.dlpds@pdsFull), axes=TRUE, lty='dotdash',  
+       border=.StemEnv$izBorderColor)  
R> plot(iz.dlpds, add=TRUE, showLogCenter=TRUE, cex=2, showNeedle=TRUE)  
R> plot(perimeter(iz.dlpds@pdsPart), add=TRUE, lty='dashed',  
+       border=.StemEnv$izBorderColor)
```




Figure 8: “distanceLimitedPDSIZ” object showing the PDS component delineation (dashed) and the full PDS inclusion zone (dot-dashed) for comparison.

11.4 The “omnibusDLPDSIZ” class

Omnibus DLPDS is discussed in Gove et al. (2013). It allows us to get estimates of attributes other than the one of the three primary selection attributes of volume, surface area or coverage area within the PDS component (if present) of a DLPDS inclusion zone. The “omnibusDLPDSIZ” class definition is *exactly* the same as the “distanceLimitedPDSIZ” class. In fact it is a subclass of the latter that adds no new slots, so we can refer directly to the information in the last section for the class definition.

The main difference between “distanceLimitedPDSIZ” and “omnibusDLPDSIZ” class objects is in the contents of the “Part” slots. The `pdsPart` slot will hold an object of class “omnibusPDSIZ”, as will the `pdsFull` slot. In addition, the `dlsPart` slot will hold an object of class “distanceLimitedM-CIZ” rather than “distanceLimitedIZ”. As mentioned above, some of these slots can also be NULL if the component is not part of the inclusion zone for a given log.

11.4.1 Object creation

Object creation is also the same for omnibus. This is because the inclusion zone is exactly the same. However, the PDS component of the sampling surface inside the inclusion zone will be variable in height, so there is no one overall estimate of the quantities of interest that can be calculated—just as in “omnibusPDSIZ”. This is because the estimates for each point within the inclusion zone rely on some function of diameter at the perpendicular. More will be covered on this in “*The InclusionZoneGrid Class*” vignette.

```
R> iz.odlpds = omnibusDLPDSIZ(dl, pds=pdsEng2, dls=dlsEng3)
R> iz.odlpds
```

```
Object of class: omnibusDLPDSIZ
```

```
-----
inclusion zone for down log omnibus distance limited PDS
-----
```

```
InclusionZone...
```

```
Units of measurement: English
```

```
Per unit area blowup factor: NA per acre
```

```
Object bounding box...
```

```
      min      max
x -1.9497475 6.6126673
y -2.9497475 5.6126673
```

```
downLog component estimates...
  Spatial ID: log:8i6r19vc
  Number of logs: NA per acre
  Volume: NA cubic feet per acre
  Surface area: NA square feet per acre
  Coverage area: NA square feet per acre
  Length: NA feet per acre
  Biomass (woody): NA per acre
  Carbon content: NA per acre

omnibusDLPDSIZ...
  PDS type: volume
  Spatial ID: odlpds:hq23i81d
  area = 25.755564 square feet (0.0005913 acres)
  Number of perimeter points: 37 (closed polygon)
  (The above summary is for the entire DLPDS region)

omnibusDLPDSIZ details...
  distance limit = 2 feet
  limiting diameter = 0.71364965 feet (8.564 in)
  distance limited component available = TRUE
  PDS component available = TRUE
  Summaries of individual DLPDS components can be viewed separately

R> class(iz.odlpds@pdsPart)

[1] "omnibusPDSIZ"
attr(,"package")
[1] "sampSurf"

R> class(iz.odlpds@dlsPart)

[1] "distanceLimitedMCIZ"
attr(,"package")
[1] "sampSurf"
```

Note particularly that the “downLog” component estimates are all NA reflecting the above point concerning the variable sampling surface within the inclusion zone. Also, compare the class types for the objects stored in the `dlsPart` and `pdsPart` listed above with that for the canonical DLPDS example above.

11.4.2 Plotting the object

A plot of this object would look *exactly* like that of Figure 8, so there is no need to repeat that here.

11.5 The “hybridDLPDSIZ” class

This method is actually the original DLPDS sampling method introduced by [Ducey et al. \(2013\)](#). It is referred to here as a “hybrid” approach because it combines both a Monte Carlo distance limited estimator with a canonical PDS estimator. The overall estimator is design-unbiased as a consequence. It was envisioned in the original account to be applicable to the selection attributes of volume and surface area (though it extends nicely to coverage area as well). The “hybridDLPDSIZ” class definition is *exactly* the same as the “distanceLimitedPDSIZ” class. In fact it is a subclass of the latter that adds no new slots, so we can refer directly to the information on the superclass for the class definition.

It follows that, as with “omnibusDLPDSIZ”, the objects in the “Part” slots will hold objects corresponding to the above. The `pdsPart` and `pdsFull` slots will hold objects of class “perpendicularDistanceIZ”, while the `dlsPart` slot will hold an object of class “distanceLimitedMCIZ”. Recall, that either of these may be `Null` if the log does not divide into the two components.

11.5.1 Object creation

Again, the inclusion zone is exactly the same as for the other distance limited protocols, so object creation is the same as well. And again, because of the Monte Carlo aspect of the distance limited component of the inclusion zone, there will be no overall estimate of the attributes. The inclusion zone will be flat in the PDS component, and sloping in the DLMCS component. More will be covered on this in “*The InclusionZoneGrid Class*” vignette.

```
R> iz.hdlpds = hybridDLPDSIZ(dl, pds=pdsEng2, dls=dlsEng3)
R> iz.hdlpds
```

```
Object of class: hybridDLPDSIZ
-----
inclusion zone for down log hybrid distance limited PDS
-----
```

```
InclusionZone...
  Units of measurement:  English
```

```
Per unit area blowup factor: NA per acre

Object bounding box...
      min      max
x -1.9497475 6.6126673
y -2.9497475 5.6126673

downLog component estimates...
  Spatial ID: log:8i6r19vc
  Number of logs: NA per acre
  Volume: NA cubic feet per acre
  Surface area: NA square feet per acre
  Coverage area: NA square feet per acre
  Length: NA feet per acre
  Biomass (woody): NA per acre
  Carbon content: NA per acre

hybridDLPDSIZ...
  PDS type: volume
  Spatial ID: hdlpds:pm3607kf
  area = 25.755564 square feet (0.0005913 acres)
  Number of perimeter points: 37 (closed polygon)
  (The above summary is for the entire DLPDS region)

hybridDLPDSIZ details...
  distance limit = 2 feet
  limiting diameter = 0.71364965 feet (8.564 in)
  distance limited component available = TRUE
  PDS component available = TRUE
  Summaries of individual DLPDS components can be viewed seperately

R> class(iz.hdlpds@pdsPart)

[1] "perpendicularDistanceIZ"
attr(,"package")
[1] "sampSurf"

R> class(iz.hdlpds@dlsPart)

[1] "distanceLimitedMCIZ"
attr(,"package")
[1] "sampSurf"
```

Note particularly that the “downLog” component estimates are all NA reflecting the above point concerning the variable sampling surface within the inclusion zone. Also, compare the class types for the objects stored in the `dlsPart` and `pdsPart` listed above with that for the canonical DLPDS example above.

11.5.2 Plotting the object

A plot of this object would look *exactly* like that of Figure 8, so there is no need to repeat that here.

12 The “standingTreeIZ” Class

This class forms the base class for methods dealing with sampling standing trees and is analogous to the “downLogIZ” class for downed logs. It is a virtual class, and adds only one slot to the “InclusionZone” class definition, that slot holds the “standingTree” object...

```
R> getClass('standingTreeIZ')
```

```
Virtual Class "standingTreeIZ" [package "sampSurf"]
```

Slots:

Name:	standingTree	description	units	bbox	spUnits
Class:	standingTree	character	character	matrix	CRS

Name:	puaBlowup	puaEstimates	userExtra
Class:	numeric	list	ANY

Extends: "InclusionZone"

Known Subclasses:

Class "circularPlotIZ", directly

Class "horizontalLineIZ", directly

Class "horizontalPointIZ", by class "circularPlotIZ", distance 2

Class "criticalHeightIZ", by class "horizontalPointIZ", distance 3

Class "importanceCHSIZ", by class "criticalHeightIZ", distance 4

Class "antitheticICHSIZ", by class "importanceCHSIZ", distance 5

Class "pairedAICHSIZ", by class "importanceCHSIZ", distance 5

13 The “circularPlotIZ” Class

Sampling standing trees with fixed-area circular plots has long been a standard method used in forestry, ecology, and related disciplines. This class is a direct descendant of the “standingTreeIZ” class and adds only one slot to its definition. The slot holds a “circularPlot” class object from the “ArealSampling” superclass.

```
R> getClass('circularPlotIZ')
```

```
Class "circularPlotIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	circularPlot	standingTree	description	units	bbox
Class:	circularPlot	standingTree	character	character	matrix
Name:	spUnits	puaBlowup	puaEstimates	userExtra	
Class:	CRS	numeric	list	ANY	

```
Extends:
```

```
Class "standingTreeIZ", directly
```

```
Class "InclusionZone", by class "standingTreeIZ", distance 2
```

```
Known Subclasses:
```

```
Class "horizontalPointIZ", directly
```

```
Class "criticalHeightIZ", by class "horizontalPointIZ", distance 2
```

```
Class "importanceCHSIZ", by class "criticalHeightIZ", distance 3
```

```
Class "antitheticICHSIZ", by class "importanceCHSIZ", distance 4
```

```
Class "pairedAICHSIZ", by class "importanceCHSIZ", distance 4
```

13.1 Object creation

The constructor method for this class takes a “standingTree” object and the fixed-area plot radius as the two signature arguments. The plot radius gets converted to an object of class “circularPlot” internally.² An example is the following for a $\frac{1}{10}$ th acre plot...

²The use of a plot radius rather than passing a “circularPlot” object is for consistency with the down woody debris sampling methods. The latter were the first methods written and regretfully, not a lot of forward thought went into their design.

```
R> sttr = standingTree(species='red oak', height=50, dbh=10,
+                       topDiam=0, center=c(x=40,y=40),
+                       units='English', vol2wgt=34.9, wgt2carbon=0.5)
R> pltRad = function(plotSize) sqrt(43560*plotSize/pi)
R> sttr.cpiz = circularPlotIZ(sttr, plotRadius = pltRad(0.1))
R> summary(sttr.cpiz)
```

Object of class: circularPlotIZ

inclusion zone for circular plot method

InclusionZone...

Units of measurement: English
Per unit area blowup factor: 10 per acre

Object bounding box...

	min	max
x	2.7822345	77.236513
y	2.7681745	77.231825

standingTree component estimates...

Spatial ID: tree:j3qf281g
Number of trees: 10 per acre
Basal area: 5.4541539 square feet per acre
Volume: 132.53546 cubic feet per acre
Surface area: 836.389 square feet per acre
Biomass (stem): 4625.4875 per acre
Carbon content: 2312.7438 per acre

circularPlotIZ...

use "summary" on the circularPlot slot for details

```
R> summary(sttr.cpiz@circularPlot)
```

Object of class: circularPlot

fixed area circular plot

ArealSampling...

units of measurement: English

```
circularPlot...  
  radius = 37.236513 feet  
  area = 4356 square feet (0.1 acres)  
  spatial units: NA  
  spatial ID: cp:j9f4q2r7  
  location (plot center)...  
    x coord: 40  
    y coord: 40  
  Number of perimeter points: 101 (closed polygon)
```

13.2 Plotting the object

As with other classes, the `plot` generic has been extended to facilitate graphical display...

```
R> plot(sttr.cpiz, axes=TRUE, cex=2)  
R> sttr.cpiz2 = circularPlotIZ(sttr, plotRadius = pltRad(0.05))  
R> plot(sttr.cpiz2, showTree=FALSE, izColor=NA, lty='dashed', add=TRUE)  
R> plot(circularPlot(pltRad(0.02), centerPoint=c(x=40,y=40), units='English'),  
+       add=TRUE, lty='dotted', izColor=NA)
```

The example in Figure 9 displays both the circular plot object and the standing tree object by default in the first command. Next, a second “circularPlotIZ” object has been added to the plot to show some of the options available in the `plot` method for this class found in the third line. It should be obvious by now that there are many ways to create the same graphical effect as is shown in these two lines. The one taken here is really overkill. For example, we could also have simply plotted the perimeter of the `circularPlot` slot in the “circularPlotIZ” object using the `perimeter` method, or the just plotted the slot object itself. Finally, if a separate inclusion zone object is not required for other use, what amounts to the same thing graphically and is simpler would be to just create and plot a `circularPlot` object as is shown in the last line of code. These examples just serve to illustrate the flexibility available that can be used in different circumstances as the need arises.

14 The “horizontalPointIZ” Class

This class encompasses what has come to be known as horizontal point sampling, angle gauge sampling, or classic Bitterlich sampling for standing trees. The inclusion zones are circular and proportional to tree basal area in this case. The class definition is...




Figure 9: Three “circularPlotIZ” objects with different radii.

```
R> getClass('horizontalPointIZ')
```

```
Class "horizontalPointIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	angleGauge	circularPlot	standingTree	description	units
Class:	angleGauge	circularPlot	standingTree	character	character

Name:	bbox	spUnits	puaBlowup	puaEstimates	userExtra
Class:	matrix	CRS	numeric	list	ANY

```
Extends:
```

```
Class "circularPlotIZ", directly
```

```
Class "standingTreeIZ", by class "circularPlotIZ", distance 2
```

Class "InclusionZone", by class "circularPlotIZ", distance 3

Known Subclasses:

Class "criticalHeightIZ", directly

Class "horizontalPointCMCIZ", directly

Class "horizontalPointISIZ", directly

Class "horizontalPointCVIZ", directly

Class "importanceCHSIZ", by class "criticalHeightIZ", distance 2

Class "antitheticICHSIZ", by class "criticalHeightIZ", distance 3

Class "pairedAICHSIZ", by class "criticalHeightIZ", distance 3

The “horizontalPointIZ” class is a subclass of the “circularPlotIZ”, and adds only one slot for the angle gauge information used to create the inclusion via an “angleGauge” object. The “circularPlotIZ” class already knows how to handle circular inclusion zones centered on a “standingTree” object. The “horizontalPointIZ” class takes advantage of this inherent functionality associated with different methods already developed for the “circularPlotIZ” class and simply makes each object’s circular plot variable (depending on the gauge angle and tree basal area), rather than fixed. As a consequence, there is no need for a separate `plot` method, for example, since the method for “circularPlotIZ” already knows how to handle circular inclusion zones. If you have followed this reasoning, this is a good example of how inheritance allows use of existing methods applied to subclass objects.

14.1 Object creation

It should not be surprising that the constructor is very similar to that for the superclass, but substituting an “angleGauge” object for the plot radius, which is determined internally based on the tree size and gauge angle.

```
R> aGauge = angleGauge(baf=10, units='English')
R> sttr.hpiz = horizontalPointIZ(sttr, aGauge)
R> summary(sttr.hpiz)
```

Object of class: horizontalPointIZ

```
-----
inclusion zone for horizontal point sampling method
-----
```

InclusionZone...

Units of measurement: English

Per unit area blowup factor: 18.334649 per acre


```

Object bounding box...
      min      max
x 12.513845 67.500000
y 12.503461 67.496539

standingTree component estimates...
  Spatial ID: tree:j3qf281g
  Number of trees: 18.334649 per acre
  Basal area: 10 square feet per acre
  Volume: 242.99912 cubic feet per acre
  Surface area: 1533.4899 square feet per acre
  Biomass (stem): 8480.6692 per acre
  Carbon content: 4240.3346 per acre

circularPlotIZ...
  use "summary" on the circularPlot slot for details

horizontalPointIZ...
  use "summary" on the angleGauge slot for details

```

```
R> sttr.hpiz@circularPlot
```

```
Object of class: circularPlot
```

```
-----
fixed area circular plot
-----
```

```
ArealSampling...
```

```
  units of measurement: English
```

```
circularPlot...
```

```
  radius = 27.5 feet
  area = 2375.8294 square feet (0.05454 acres)
  spatial units: NA
  spatial ID: hps:83da6yf5
  location (plot center)...
    x coord: 40
    y coord: 40
  Number of perimeter points: 101 (closed polygon)
```

The diameter of the “standingTree” object is 10 inches, and the plot radius factor for a 10 BAF factor prism is 2.75, so the variable plot radius for this tree is 27.5 feet.

14.2 Plotting the object

An object of class “horizontalPointIZ” can be plotted as...

```
R> plot(sttr.hpiz, axes=TRUE, cex=2)
```




Figure 10: A “horizontalPointIZ” object.

Because the `plot` method for the “circularPlotIZ” class is used via inheritance here, there is nothing new to remark about in Figure 10.

14.3 The horizontalPointCMCIZ Class

This class is for two-stage horizontal point sampling for volume estimation, where crude Monte Carlo is used to subsample the tree for volume. The class definition is...

```
R> showClass('horizontalPointCMCIZ')
```

```
Class "horizontalPointCMCIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	mcsObj	antithetic	proxy
Class:	MonteCarloSampling	logical	character
Name:	angleGauge	circularPlot	standingTree
Class:	angleGauge	circularPlot	standingTree
Name:	description	units	bbox
Class:	character	character	matrix
Name:	spUnits	puaBlowup	puaEstimates
Class:	CRS	numeric	list
Name:	userExtra		
Class:	ANY		

```
Extends:
```

```
Class "MonteCarloSamplingIZ", directly
Class "horizontalPointIZ", directly
Class "horizontalPointMonteCarloSamplingIZ", directly
Class "circularPlotIZ", by class "horizontalPointIZ", distance 2
Class "standingTreeIZ", by class "horizontalPointIZ", distance 3
Class "InclusionZone", by class "horizontalPointIZ", distance 4
```

This class is a combination of the “MonteCarloSamplingIZ” and “horizontalPointIZ” class definitions via inheritance. The first three slots in the above class definition are supplied by the “MonteCarloSamplingIZ” class, and the rest are supplied by the “horizontalPointIZ” class. All of the later slots will therefore define a valid “horizontalPointIZ” object, and the usual `plot` and `summary` routines will display the same information. The “MonteCarloSamplingIZ” slots carry information that will eventually be used to grid the volume surface in the corresponding `izGrid` constructor. More details on this can be found in [Gove \(2013\)](#) and [Gove \(2011\)](#).

14.4 The horizontalPointISIZ Class

This class is for two-stage horizontal point sampling for volume estimation, where importance sampling is used to subsample the tree for volume. The class definition is...

```
R> showClass('horizontalPointISIZ')
```

```
Class "horizontalPointISIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	mcsObj	antithetic	proxy
Class:	MonteCarloSampling	logical	character

Name:	angleGauge	circularPlot	standingTree
Class:	angleGauge	circularPlot	standingTree

Name:	description	units	bbox
Class:	character	character	matrix

Name:	spUnits	puaBlowup	puaEstimates
Class:	CRS	numeric	list

Name:	userExtra
Class:	ANY

```
Extends:
```

```
Class "MonteCarloSamplingIZ", directly
```

```
Class "horizontalPointIZ", directly
```

```
Class "horizontalPointMonteCarloSamplingIZ", directly
```

```
Class "circularPlotIZ", by class "horizontalPointIZ", distance 2
```

```
Class "standingTreeIZ", by class "horizontalPointIZ", distance 3
```

```
Class "InclusionZone", by class "horizontalPointIZ", distance 4
```

The same information applies here as to crude Monte Carlo subsampling, see § 14.3 for details.

14.5 The horizontalPointCVIZ Class

This class is for two-stage horizontal point sampling for volume estimation, where control variate sampling is used to subsample the tree for volume. The class definition is...

```
R> showClass('horizontalPointCVIZ')
```

```
Class "horizontalPointCVIZ" [package "sampSurf"]
```

Slots:

Name:	mcsObj	antithetic	proxy
Class:	MonteCarloSampling	logical	character
Name:	angleGauge	circularPlot	standingTree
Class:	angleGauge	circularPlot	standingTree
Name:	description	units	bbox
Class:	character	character	matrix
Name:	spUnits	puaBlowup	puaEstimates
Class:	CRS	numeric	list
Name:	userExtra		
Class:	ANY		

Extends:

Class "MonteCarloSamplingIZ", directly
 Class "horizontalPointIZ", directly
 Class "horizontalPointMonteCarloSamplingIZ", directly
 Class "circularPlotIZ", by class "horizontalPointIZ", distance 2
 Class "standingTreeIZ", by class "horizontalPointIZ", distance 3
 Class "InclusionZone", by class "horizontalPointIZ", distance 4

The same information applies here as to crude Monte Carlo subsampling, see § 14.3 for details.

15 The “horizontalLineIZ” Class

The “horizontalLineIZ” class is for horizontal line sampling of standing trees with an angle gauge (e.g., [Gregoire and Valentine, 2008](#), p. 359). The inclusion zones are rectangular and proportional to tree diameter at breast height. The class definition is...

```
R> showClass('horizontalLineIZ')
```

```
Class "horizontalLineIZ" [package "sampSurf"]
```

Slots:

Name:	angleGauge	lineSegment	width	length
-------	------------	-------------	-------	--------

Class:	angleGauge	lineSegment	numeric	numeric
Name:	izPerim	area	perimeter	pgArea
Class:	matrix	numeric	SpatialPolygons	numeric
Name:	standingTree	description	units	bbox
Class:	standingTree	character	character	matrix
Name:	spUnits	puaBlowup	puaEstimates	userExtra
Class:	CRS	numeric	list	ANY

Extends:

Class "standingTreeIZ", directly

Class "InclusionZone", by class "standingTreeIZ", distance 2

15.1 Class slots

The following slots have been added to this subclass; note that it is a direct subclass of “standingTree”...

- *angleGauge*: An object of class “angleGauge” used in conjunction with the tree diameter to determine the inclusion zone width.
- *lineSegment*: An object of class “lineSegment” used to determine the length of the inclusion zone.
- *width*: The width of the inclusion zone.
- *length*: The length of the inclusion zone.
- *izPerim*: A matrix representation of the inclusion zone in homogeneous coordinates. This can be manipulated and plotted as desired for easy access to the inclusion zone where needed.
- *area*: The exact area of the inclusion zone.
- *perimeter*: This is the inclusion zone perimeter as a “SpatialPolygons” object.
- *pgArea*: This is the area of the inclusion zone as calculated from the polygon in the **perimeter** slot using the “SpatialPolygons” object. As such, it is an approximation of the true area of the inclusion zone, which is given in the **area** slot. This just enables us to see how close the graphic representation is to the real area.

15.2 Object creation

The constructor method for this class takes “standingTree” and “angleGauge” objects as well as the line length as the signature arguments. The line **orientation** defaults to north (0 degrees). An object of class “lineSegment” is created internally from the **lineLength** and **orientation** arguments, centered on the tree location. An example follows...

```
R> aGauge = angleGauge(baf=75, units='English')
R> sttr.hliz = horizontalLineIZ(sttr, angleGauge = aGauge, lineLength = 50,
+                               orientation = 345, units='English')
R> summary(sttr.hliz)
```

```
Object of class: horizontalLineIZ
```

```
-----
inclusion zone for horizontal line sampling method
-----
```

```
InclusionZone...
```

```
  Units of measurement:  English
```

```
  Per unit area blowup factor: 43.379627 per acre
```

```
Object bounding box...
```

```
      min      max
x 23.830102 56.169898
y 13.252902 66.747098
```

```
standingTree component estimates...
```

```
  Spatial ID: tree:j3qf281g
```

```
  Number of trees: 43.379627 per acre
```

```
  Basal area: 23.659916 square feet per acre
```

```
  Volume: 574.93387 cubic feet per acre
```

```
  Surface area: 3628.2242 square feet per acre
```

```
  Biomass (stem): 20065.192 per acre
```

```
  Carbon content: 10032.596 per acre
```

```
horizontalLineIZ...
```

```
  Inclusion zone length = 50 feet
```

```
  Inclusion zone width = 20.08316 feet
```

```
  Inclusion zone area = 1004.158 square feet
```

```
  Note: use "summary" on the angleGauge & lineSegment slots for details
```

The diameter of the “standingTree” object is 10 inches, and the plot radius factor for a 75 BAF factor prism is 1, so the variable plot width for this tree is 20.1 feet as shown above.³

15.3 Plotting the object

An object of class “horizontalLineIZ” can be plotted as, e.g.,...

```
R> plot(sttr.hliz, axes=TRUE, cex=1.5)
```




Figure 11: A “horizontalLineIZ” object.

Figure 11 shows the results. Note that the line segment is shown as the dashed line through the tree (the segment center is not shown by default as it would overlap the tree in the display). The

³The 75 BAF angle gauge is a nice BAF to use with horizontal line sampling because checking borderline trees is simple with a plot radius of one foot for every inch in diameter.

inclusion zone is centered on the tree with the desired orientation. The `cex` argument is used to enlarge the location of the center of the tree.

16 The “criticalHeightIZ” Class

Critical height sampling (CHS) is a design-unbiased method for estimating volumes of standing trees based on horizontal point sampling (§ 14). The inclusion zones are exactly the same as in HPS, when the reference height is at breast height (BH). The reference height can also be at the butt (ground level), in which case the inclusion zone will be larger than that for HPS. The class definition is...

```
R> getClass('criticalHeightIZ')
```

```
Class "criticalHeightIZ" [package "sampSurf"]
```

Slots:

Name:	referenceHeight	angleGauge	circularPlot	standingTree
Class:	character	angleGauge	circularPlot	standingTree
Name:	description	units	bbox	spUnits
Class:	character	character	matrix	CRS
Name:	puaBlowup	puaEstimates	userExtra	
Class:	numeric	list	ANY	

Extends:

```
Class "horizontalPointIZ", directly
Class "circularPlotIZ", by class "horizontalPointIZ", distance 2
Class "standingTreeIZ", by class "horizontalPointIZ", distance 3
Class "InclusionZone", by class "horizontalPointIZ", distance 4
```

Known Subclasses:

```
Class "importanceCHSIZ", directly
Class "antitheticICHSIZ", by class "importanceCHSIZ", distance 2
Class "pairedAICHSIZ", by class "importanceCHSIZ", distance 2
```

Note that “criticalHeightIZ” is a direct subclass of “horizontalPointIZ”. The only new slot is the `referenceHeight` slot, which is a character string that must match one of the following...

```
R> .StemEnv$referenceCHSIZ
```

```
[1] "butt" "dbh"
```

Please see § 14 for the other slot definitions.

16.1 Object creation

The constructor is very similar to that for the superclass...

```
R> aGauge = angleGauge(baf=10, units='English')
R> sttr.chsiz = criticalHeightIZ(sttr, aGauge, referenceHeight='dbh')
R> summary(sttr.chsiz)
```

```
Object of class: criticalHeightIZ
```

```
-----
inclusion zone for critical height sampling method
-----
```

```
InclusionZone...
```

```
  Units of measurement:  English
```

```
  Per unit area blowup factor: 10 per acre
```

```
Object bounding box...
```

```
      min      max
x 12.513845 67.500000
y 12.503461 67.496539
```

```
standingTree component estimates...
```

```
  Spatial ID: tree:j3qf281g
```

```
  Number of trees: NA per acre
```

```
  Basal area: NA square feet per acre
```

```
  Volume: NA cubic feet per acre
```

```
  Surface area: NA square feet per acre
```

```
  Biomass (stem): NA per acre
```

```
  Carbon content: NA per acre
```

```
circularPlotIZ...
```

```
  use "summary" on the circularPlot slot for details
```

```
horizontalPointIZ...
  use "summary" on the angleGauge slot for details

criticalHeightIZ...
  Inclusion zone reference height is: dbh
```

One thing to note is that all of the estimates are NA in the above object. There are two reasons for this. First, critical height is only used for estimating tree volume, so all other attributes are not applicable. Second, the estimates are different for each “ring” of radius that we step back away from the tree within the inclusion zone, and depend on the grid cell size. Therefore the estimates for the tree get calculated in the `izGrid` method for CHS (see *The “InclusionZoneGrid” Class* vignette for details), producing the variable surface within each tree’s inclusion zone.

16.2 Plotting the object

Plotting the object is the same as for “horizontalPointIZ”, and in this case, will look exactly the same as the zone in Figure 10, since we have sampled at BH.

16.3 The “importanceCHSIZ” Class

Importance sampling can be combined with critical height in the hopes of reducing the variance of the CHS estimator (which is already pretty good). This class adds an importance sampling variant that chooses an upper stem cross-sectional area through a taper function that makes use of the critical diameter associated with the critical height for a given sample point. Details are too much to cover here and are found in [Lynch and Gove \(2013\)](#). Suffice it to say that the importance sampling point so chosen is constrained by the critical height, producing similar sampling surfaces, but with better variance.

This class is a subclass of “criticalHeightIZ” and is defined as...

```
R> getClass('importanceCHSIZ')
```

```
Class "importanceCHSIZ" [package "sampSurf"]
```

```
Slots:
```

Name:	referenceHeight	angleGauge	circularPlot	standingTree
Class:	character	angleGauge	circularPlot	standingTree

Name:	description	units	bbox	spUnits
Class:	character	character	matrix	CRS

Name:	puaBlowup	puaEstimates	userExtra
Class:	numeric	list	ANY

Extends:

Class "criticalHeightIZ", directly
 Class "horizontalPointIZ", by class "criticalHeightIZ", distance 2
 Class "circularPlotIZ", by class "criticalHeightIZ", distance 3
 Class "standingTreeIZ", by class "criticalHeightIZ", distance 4
 Class "InclusionZone", by class "criticalHeightIZ", distance 5

Known Subclasses: "antitheticICHsIZ", "pairedAICHsIZ"

Note that there are no new slots added to this class, please see § 16 for details.

16.3.1 Object creation

The constructor is very similar to that for the superclass...

```
R> sttr.ichsiz = importanceCHsIZ(sttr, aGauge, referenceHeight='dbh')
R> summary(sttr.ichsiz)
```

Object of class: importanceCHsIZ

```
-----
inclusion zone for importance CH sampling method
-----
```

InclusionZone...

Units of measurement: English
 Per unit area blowup factor: 10 per acre

Object bounding box...

```
      min      max
x 12.513845 67.500000
y 12.503461 67.496539
```

standingTree component estimates...

Spatial ID: tree:j3qf281g

```

Number of trees: NA per acre
Basal area: NA square feet per acre
Volume: NA cubic feet per acre
Surface area: NA square feet per acre
Biomass (stem): NA per acre
Carbon content: NA per acre

circularPlotIZ...
  use "summary" on the circularPlot slot for details

horizontalPointIZ...
  use "summary" on the angleGauge slot for details

criticalHeightIZ...
  Inclusion zone reference height is: dbh

```

16.3.2 Plotting the object

Plotting the object is the same as for “horizontalPointIZ”, and in this case, will look exactly the same as the zone in Figure 10, since we have sampled at BH.

16.4 The “antitheticICHSIZ” Class

Antithetic sampling can be used to move the importance sampling point (based on CHS) on the tree bole so that it is easier to measure. Details are again given in [Lynch and Gove \(2013\)](#). This is a subclass of “importanceCHSIZ”...

```
R> getClass('antitheticICHSIZ')
```

```
Class "antitheticICHSIZ" [package "sampSurf"]
```

Slots:

Name:	referenceHeight	angleGauge	circularPlot	standingTree
Class:	character	angleGauge	circularPlot	standingTree
Name:	description	units	bbox	spUnits
Class:	character	character	matrix	CRS
Name:	puaBlowup	puaEstimates	userExtra	

Class: numeric list ANY

Extends:

Class "importanceCHSIZ", directly

Class "criticalHeightIZ", by class "importanceCHSIZ", distance 2

Class "horizontalPointIZ", by class "importanceCHSIZ", distance 3

Class "circularPlotIZ", by class "importanceCHSIZ", distance 4

Class "standingTreeIZ", by class "importanceCHSIZ", distance 5

Class "InclusionZone", by class "importanceCHSIZ", distance 6

Note that there are no new slots added to this class, please see § 16 for details.

16.4.1 Object creation

The constructor is very similar to that for the superclass...

```
R> sttr.aichsiz = antitheticICHSIZ(sttr, aGauge, referenceHeight='dbh')
R> summary(sttr.aichsiz)
```

Object of class: antitheticICHSIZ

inclusion zone for antithetic ICH sampling method

InclusionZone...

Units of measurement: English

Per unit area blowup factor: 10 per acre

Object bounding box...

```
      min      max
x 12.513845 67.500000
y 12.503461 67.496539
```

standingTree component estimates...

Spatial ID: tree:j3qf281g

Number of trees: NA per acre

Basal area: NA square feet per acre

Volume: NA cubic feet per acre

Surface area: NA square feet per acre

Biomass (stem): NA per acre

```

Carbon content: NA per acre

circularPlotIZ...
  use "summary" on the circularPlot slot for details

horizontalPointIZ...
  use "summary" on the angleGauge slot for details

criticalHeightIZ...
  Inclusion zone reference height is: dbh

```

16.4.2 Plotting the object

Plotting the object is the same as for “horizontalPointIZ”, and in this case, will look exactly the same as the zone in Figure 10, since we have sampled at BH.

16.5 The “pairedAICHSIZ” Class

A paired antithetic sampling estimator was again given in [Lynch and Gove \(2013\)](#), consisting of two measurements per tree. This, like “antitheticICHs”, is a subclass of “importanceCHSIZ”...

```
R> getClass('pairedAICHSIZ')
```

```
Class "pairedAICHSIZ" [package "sampSurf"]
```

Slots:

Name:	referenceHeight	angleGauge	circularPlot	standingTree
Class:	character	angleGauge	circularPlot	standingTree
Name:	description	units	bbox	spUnits
Class:	character	character	matrix	CRS
Name:	puaBlowup	puaEstimates	userExtra	
Class:	numeric	list	ANY	

Extends:

```

Class "importanceCHSIZ", directly
Class "criticalHeightIZ", by class "importanceCHSIZ", distance 2
Class "horizontalPointIZ", by class "importanceCHSIZ", distance 3

```

Class "circularPlotIZ", by class "importanceCHSIZ", distance 4
 Class "standingTreeIZ", by class "importanceCHSIZ", distance 5
 Class "InclusionZone", by class "importanceCHSIZ", distance 6

Note that there are no new slots added to this class, please see § 16 for details.

16.5.1 Object creation

The constructor is very similar to that for the superclass...

```
R> sttr.paichsiz = pairedAICHsIZ(sttr, aGauge, referenceHeight='dbh')
R> summary(sttr.paichsiz)
```

Object of class: pairedAICHsIZ

```
-----
inclusion zone for paired antithetic ICH sampling method
-----
```

InclusionZone...

```
Units of measurement: English
Per unit area blowup factor: 10 per acre
```

Object bounding box...

```
      min      max
x 12.513845 67.500000
y 12.503461 67.496539
```

standingTree component estimates...

```
Spatial ID: tree:j3qf281g
Number of trees: NA per acre
Basal area: NA square feet per acre
Volume: NA cubic feet per acre
Surface area: NA square feet per acre
Biomass (stem): NA per acre
Carbon content: NA per acre
```

circularPlotIZ...

```
use "summary" on the circularPlot slot for details
```

horizontalPointIZ...


```
use "summary" on the angleGauge slot for details

criticalHeightIZ...
  Inclusion zone reference height is: dbh
```

16.5.2 Plotting the object

Plotting the object is the same as for “horizontalPointIZ”, and in this case, will look exactly the same as the zone in Figure 10, since we have sampled at BH.

16.5.3 You’ve seen one...

It is easy to wonder why one would want all these different classes of objects (plus CHS) if they produce the same inclusion zones? The answer is that the sampling surfaces within these protocols are different because the estimators are different. The associated “InclusionZone” subclass objects are the container for the surfaces in a sense. This will become clear in *The “InclusionZoneGrid” Class* vignette, and it is no different than what we have already encountered with some of the protocols with PDS or the DLMCS methods. So in the larger scheme of things within **sampSurf**, having different classes for each of these protocols facilitates the subsequent programming of constructor methods in a strict S4 object oriented sense.

17 Container Classes

As we’ve mentioned in other vignettes, there needs to be a mechanism to have multiple versions of, e.g., “downLogIZ” objects or subclasses thereof stored in a population of sorts. One could just use a **list** structure, and this would work fine, but then there would be no ability to associate methods. So it is better to adopt an S4 class structure, albeit simple, that can encapsulate the behavior desired. This means there needs to be class and constructor methods, along with summary, plot, etc. for this collection of objects.

17.1 Class “izContainer”

This is a virtual base container class that may be extended for specific containers of different types.

```
R> showClass('izContainer')
```

```
Class "izContainer" [package "sampSurf"]
```

```
Slots:
```

```
Name:      iZones      units      bbox description
Class:      list      character      matrix      character
```

```
Known Subclasses: "downLogIZs", "standingTreeIZs"
```

At present, it holds a list of “InclusionZone” subclass objects in the `iZones` slot, and the overall bounding box for the collection or population, along with a description and units for all objects. The bounding box is useful in plotting and will also be used in the sampling surface routines.

This is not yet a fully functional ‘container’ class in the sense of *Java* or *C++*. For example, there is no functionality for adding, deleting, or replacing container objects at present. If you need to do any of this, it is best to just remake the collection (simple enough) with the new changes or you will need to worry about changing the bounding box as well.

17.2 Class “downLogIZs”

This container holds a collection of “downlogIZ” objects along with some spatial information. It is a usable direct descendant of the “izContainer” class...

```
R> showClass('downLogIZs')
```

```
Class "downLogIZs" [package "sampSurf"]
```

```
Slots:
```

```
Name:      iZones      units      bbox description
Class:      list      character      matrix      character
```

```
Extends: "izContainer"
```

17.2.1 Class construction

In keeping with the previous naming conventions, the constructor function for this class is `downLogIZs`. A collection can be created via the following steps, though there are alternatives in each case...

1. *Measured population:*

- (a) Use the field measurements to make individual “downLog” objects, and then place them into a `list` container.
- (b) Create valid “downLogIZ” subclass objects for each log—they all must be of the same class.
- (c) Use the “downLogIZs” constructor on this list of logs, to create the collection.

2. *Synthetic population:*

- (a) Draw a sample of “downLog”s randomly within some sample area, using the “downLogs” constructor.
- (b) Then create a `list` of “downLogIZ” subclass objects.
- (c) Finally, group these into the container class with “downLogIZs”.

The above are essentially the same in practice, as similar steps are followed whether a synthetic or real population of logs is used. At present, one must specify objects of exactly the same subclass in the `list` constructor. That is, you can not mix sampling methods as demonstrated below. Please see the “downLogs” constructor and “*The Stem Class*” vignette for more options in each of the first steps above.

In the first example, we will pretend that `d1` and `d12` are logs from a field sample, and we then have made sausage inclusion zones for these in the example above. Therefore, we follow the rest of the steps...

```
R> sal = list(sa,sa2)
R> sapply(sal, class)
```

```
[1] "sausageIZ" "sausageIZ"
```

```
R> iza = downLogIZs(sal, description = 'two inclusion zones...\nboth sausage')
R> sapply(iza@iZones, class)
```

```
[1] "sausageIZ" "sausageIZ"
```

```
R> summary(iza)
```

```
Container object of class: downLogIZs
```

```
-----
```

```

two inclusion zones...
both sausage
-----
There are 2 inclusion zones in the population
Inclusion zones are of class: sausageIZ
Units of measurement: English
Summary of inclusion zone areas in square feet...
      Min.      1st Qu.      Median      Mean      3rd Qu.      Max.
118.540000  133.540000  148.540000  148.540000  163.540000  178.540000
      var      SDev
1800.000000   42.426407

Encapulating bounding box...
      min      max
x -5.5348916  11.535534
y -6.5348916  10.535534

```

The above example is fine, because both of the member objects in the list used to construct the “downLogIZs” object were of class “sausageIZ”. However, in the following example, we are mixing sampling methods, which is not allowed...

```

R> sal2 = list(su,sa)
R> iizs = tryCatch(downLogIZs(sal2), error = function(e) e)
R> if(is(iizs, 'simpleError')) cat(iizs[[1]],'\n')

```

invalid class "downLogIZs" object: You can not mix inclusion classes in the population!

```

R> sapply(sal2,class)

```

```

[1] "standUpIZ" "sausageIZ"

```

It is very simple to draw a simulated population of logs plus their inclusion zone. As shown below, this can be done for a log population of any size. Since the logs are stored within the objects as a list structure, we can apply the list-based object constructors via `lapply` to return a new list that can directly be converted to a container object. However, it is perhaps simpler to use the alternative constructor that works directly on a “downLogs” object collection—both methods are illustrated in the following...

```

R> dls = downLogs(6, units='English', buttDiam=c(6,20))
R> dls.su = lapply(dls@logs, 'standUpIZ', plotRadius=5)

```

```
R> iza.su = downLogIZs(dls.su)
R> iza.sa = downLogIZs(dls, iZone = 'sausageIZ', plotRadius=5)
```

Both constructors are equally useful, the second form simply builds the list internally using `lapply`, then calls the first constructor on the `list` object. Note that the code in the second and third lines can be combined into one command, but is separated here for clarity.

17.2.2 Plotting the object

There is a plot method for “downLogIZs” objects that works as usual.

In the case of the first example, where the “downLogIZs” object was created using ‘field data,’ we have generate Figure 12...

```
R> plot(iza, axes=TRUE, showLogCenter=TRUE, cex=2, showNeedle=TRUE)
```

In the second example, where we use synthetic logs, we generate Figure 13 showing the “standUpIZ” inclusion zones superimposed over the “sausageIZ” inclusion zones, purely for comparison...

```
R> plot(iza.sa, axes=TRUE, showLogCenter=TRUE, cex=2, showNeedle=TRUE)
R> plot(iza.su, add=TRUE, izColor=NA)
```

Note that in generating Figure 13, we have plotted the sausage collection before the standup collection, because the former has a larger overall bounding box that will contain all of the collected objects, regardless of their “InclusionZone” classes. Note again, however, the restriction that within a collection, all of the objects must share the same “InclusionZone” class.

17.3 Class “standingTreeIZs”

This container holds a collection of “standingTreeIZ” objects along with some spatial information. It is a usable direct descendant of the “izContainer” class...

```
R> showClass('standingTreeIZs')
```

```
Class "standingTreeIZs" [package "sampSurf"]
```




Figure 12: “downLogIZs” object with “sausageIZ” objects in the container.

Slots:

Name:	izones	units	bbox	description
Class:	list	character	matrix	character

Extends: "izContainer"

The class is the standing tree analog to the “downLogIZs” class presented above.

17.3.1 Class construction

Because the mechanisms for class construction from measured trees or synthetically generated collections are analogous to those for “downLogIZs”, only a simple example will be given here. For more details see the previous section and substitute the appropriate standing tree-related functions.




Figure 13: “downLogIZs” object of “sausageIZ” objects, with “standUpIZ” objects superimposed.

```
R> etract = Tract(c(x=209,y=209),cellSize=0.5, units='English')
R> ebuffTr = bufferedTract(30, etract)
R> sttrs = standingTrees(10, ebuffTr, dbhs=c(5,12), units='English')
R> sttrs.hpizs = standingTreeIZs(lapply(sttrs@trees, 'horizontalPointIZ',
+                                     angleGauge = aGauge))
R> sttrs.hpizs
```

Container object of class: standingTreeIZs

There are 10 inclusion zones in the population
 Inclusion zones are of class: horizontalPointIZ
 Units of measurement: English
 Summary of inclusion zone areas in square feet...

Min.	1st Qu.	Median	Mean	3rd Qu.	Max.
637.49000	918.43000	1266.30000	1624.90000	2112.00000	3163.90000
var	SDev				
875037.26846	935.43427				

Encapulating bounding box...

	min	max
x	27.423438	186.85999
y	38.961710	194.29711

```
R> sapply(sttrs.hpizs@iZones, class)
```

tree.1	tree.2	tree.3	tree.4
"horizontalPointIZ"	"horizontalPointIZ"	"horizontalPointIZ"	"horizontalPointIZ"
tree.5	tree.6	tree.7	tree.8
"horizontalPointIZ"	"horizontalPointIZ"	"horizontalPointIZ"	"horizontalPointIZ"
tree.9	tree.10		
"horizontalPointIZ"	"horizontalPointIZ"		

Finally, let's just look at how to extract a few of the components of the collection—remember, diameters are stored internally in the same units as length (feet in this example)...

```
R> sapply(sttrs@trees,function(x)x@dbh)*12 #dbh in inches
```

tree.1	tree.2	tree.3	tree.4	tree.5	tree.6	tree.7	tree.8	tree.9	tree.10
5.39	5.18	8.99	7.21	7.39	5.89	11.54	11.43	9.57	7.11

```
R> sapply(sttrs@trees,function(x)x@dbh)*aGauge@PRF #plot radii (ft)
```

tree.1	tree.2	tree.3	tree.4	tree.5	tree.6	tree.7	tree.8	tree.9	tree.10
14.8225	14.2450	24.7225	19.8275	20.3225	16.1975	31.7350	31.4325	26.3175	19.5525

```
R> sttrs.hpizs@iZones$tree.1@circularPlot@radius #plot radius for tree 1
```

```
[1] 14.8225
```

```
R> sapply(sttrs.hpizs@iZones,function(x)x@circularPlot@radius) #plot radii (ft)
```



```

tree.1 tree.2 tree.3 tree.4 tree.5 tree.6 tree.7 tree.8 tree.9 tree.10
14.8225 14.2450 24.7225 19.8275 20.3225 16.1975 31.7350 31.4325 26.3175 19.5525

```

The first line shows how to extract the DBH values from the “standingTrees” object. The second illustrates how to calculate the plot radii from this information. However, it has already been calculated and stored in the inclusion zone for each of the trees, recalculation is therefore unnecessary. This information is embedded a bit deep into the object as shown in the penultimate line, but can be easily accessed. Since the `iZones` slot is a simple list, we can use the `sapply` function to cycle over all the individual tree inclusion zones in the list and extract the `radius` slot from the “circularPlot” object stored within each tree’s inclusion zone (see §14 for more information).

17.3.2 Plotting the object

There is a plot method for “standingTreeIZs” objects that works as usual.

```
R> plot(sttrs.hpizs, axes=TRUE)
```

17.4 Container coercion

It may be useful at times to coerce or change the container collection from its current class to something simpler. For example, it is not necessarily straightforward to work backwards and extract the collection of “Stem” objects from an “izContainer” object. To this end, the general `S4 as` method has been adapted to container classes to coerce them to simpler forms. The following applies to objects that are a subclass of “izContainer”.

For example, the “sampSurf” class stores an “izContainer” object in one of its slots. One of the constructors for the “sampSurf” objects automates the generation of the synthetic “Stem” population, and the only place it is accessible in the “sampSurf” object is within this “izContainer” slot.⁴ But it might be useful to have the stem information available for some other purpose. To extract the stem information from a subclass object of “izContainer”, apply the following steps...

```
R> stdTrees = as(sttrs.hpizs, 'standingTrees')
R> class(stdTrees)
```

```

[1] "standingTrees"
attr(,"package")
[1] "sampSurf"

```

⁴See *The “sampSurf” Class vignette* for more details.




Figure 14: “standingTreeIZs” object under horizontal point sampling.

```
R> as(stdTrees, 'data.frame')
```

	species	height	dbh	topDiam	solidType	x	y
1	hemlock	14.23	5.39	3.34	1.5	132.288697	114.388693
2	sm	7.62	5.18	2.76	3.7	112.188595	100.429216
3	shagbark hickory	13.84	8.99	6.81	5.7	137.206651	111.549651
4	rm	6.26	7.21	2.99	5.7	160.241366	162.141079
5	shagbark hickory	9.25	7.39	6.13	9.8	47.735707	59.281651
6	rm	8.46	5.89	3.68	2.4	135.316579	172.752471
7	BW	13.34	11.54	6.21	9.7	155.124993	162.566105
8	rm	10.09	11.43	7.90	1.4	78.045849	138.896218
9	BW	11.58	9.57	6.45	7.9	139.550466	115.245929
10	sm	13.37	7.11	5.07	5.7	149.476420	159.917420

The first line of code extracts all of the individual “standingTree” objects and bundles them into a

“standingTrees” container for easy handling, discarding all of the “InclusionZone” subclass information in the process. Then this collection is coerced to a “data.frame” in the last line, with diameters appropriately converted from feet to inches.

Once we know how this works, it can be simpler to just string the commands together as in the following “downLogIZs” object collection created earlier...

```
R> as( as(izs.sa, 'downLogs'), 'data.frame')
```

	species	logLen	buttDiam	topDiam	solidType	x	y
1	Picea glauca	3.23	8.23	5.89	6.1	47.325841	16.0621027
2	wp	1.68	11.08	8.64	2.9	29.782993	44.3609677
3	shagbark hickory	4.80	19.21	0.58	2.5	10.366026	49.9013624
4	wp	2.24	6.48	4.61	4.0	74.060887	37.4906937
5	hemlock	2.87	14.67	12.83	6.3	74.432935	41.8320043
6	rm	2.27	12.81	8.86	2.1	68.650088	7.1794063

	logAngle	logAngle.D
1	1.3555693	77.668399
2	4.6409483	265.906749
3	4.1581264	238.243091
4	2.9574916	169.451788
5	4.7146564	270.129913
6	4.7368793	271.403191

References

- M. J. Ducey, M. S. Williams, J. H. Gove, and H. T. Valentine. Simultaneous unbiased estimates of multiple downed wood attributes in perpendicular distance sampling. *Canadian Journal of Forest Research*, 38:2044–2051, 2008. 23, 28
- M. J. Ducey, M. S. Williams, J. H. Gove, S. Roberge, and R. S. Kenning. Distance limited perpendicular distance sampling for coarse woody material: Theory and field results. *Forestry*, 86: 119–128, 2013. 33, 41
- J. H. Gove. *Monte Carlo Sampling Methods in sampSurf*, 2013. URL <http://CRAN.R-project.org/package=sampSurf>. *sampSurf* package vignette. 51
- J. H. Gove. *The “InclusionZoneGrid” Class*, 2011. URL <http://CRAN.R-project.org/package=sampSurf>. *sampSurf* package vignette. 51
- J. H. Gove and P. C. Van Deusen. On fixed-area plot sampling for downed coarse woody debris. *Forestry*, 84(2):109–117, 2011. 6, 9, 13, 14, 17

- J. H. Gove, A. Ringvall, G. Ståhl, and M. J. Ducey. Point relascope sampling of downed coarse woody debris. *Canadian Journal of Forest Research*, 29(11):1718–1726, 1999. 19
- J. H. Gove, M. J. Ducey, A. Ringvall, and G. Ståhl. Point relascope sampling: A new way to assess down coarse woody debris. *Journal of Forestry*, 4:4–11, 2001. 19
- J. H. Gove, M. J. Ducey, and H. T. Valentine. A distance limited method for sampling downed coarse woody debris. *Forest Ecology and Management*, 282:53–62, 2012. 29, 31
- J. H. Gove, M. J. Ducey, H. T. Valentine, and M. S. Williams. A comprehensive comparison of the perpendicular distance method for sampling downed coarse woody debris. *Forestry*, 86:129–143, 2013. 39
- T. G. Gregoire and H. T. Valentine. *Sampling strategies for natural resources and the environment*. Applied environmental statistics. Chapman & Hall/CRC, N.Y., 2008. 53
- T. B. Lynch and J. H. Gove. An antithetic variate to facilitate upper-stem height measurements for critical height sampling with importance sampling. *Canadian Journal of Forest Research*, 2013. (In review). 59, 61, 63
- M. S. Williams and J. H. Gove. Perpendicular distance sampling: an alternative method for sampling downed coarse woody debris. *Canadian Journal of Forest Research*, 33:1564–1579, 2003. 23
- M. S. Williams, M. J. Ducey, and J. H. Gove. Assessing surface area of coarse woody debris with line intersect and perpendicular distance sampling. *Canadian Journal of Forest Research*, 35: 949–960, 2005. 23